

Mounting the controller on

Leave a clearance of at least 16" to the left of controller box to allow the cover to be removed for

Dry contact 15 A RES, 50/60 Hz 120 VAC (1HP), 240VAC (2HP)

Tungsten (Light Bulb): 8.3A max at 120VAC

Load Supply:

Relays 1-14:

Cable entry:

Drill holes at the bottom of the enclosure to allow wires to be introduced in the controller. Do not drill the top or side panels of the enclosure.

Backup Thermostats:

The backup thermostats are shown for illustration purposes only. Sufficient backup thermostats must be used to ensure ventilation if the controller loses power.

120-240VAC, 50-60Hz, 12-24VDC

We recommend installing a fuse box on each stage



Water Meter: The water meter output should be a dry contact and should not pulse faster than 60 times a second (60Hz).

A 22/12 AWG gauge cable no longer than 2000 feet (0.6 km) can be used to connect the water meter. Do not use a cable longer than 2000 feet even if a larger cable is used.

Do not run the meter cable outside the building!


Notes:


- 1. Installation of a good quality alarm system is strongly suggested to warn of power failures and high/low temperatures.
- 2. Provide a surge protection (including lightning protection) from the power supply to the controller and from the control to the sensors. Consult a certified electrician if required.
- 3. Same phases must be used to power the variable fans and the controls on 3 phases power.
- 4. Install low voltage wires (probes. whisker switch, potentiometer) at least 12 inches (30 cm) away from high voltage wires (230120VAC, 24VDC). Always cross low and high voltage wires at a 90° angle.

Potentiometer's Color Legend

| | COMMANDER ACTUATOR | VON WEISE ACTUATOR |
|---|-----------------------|-----------------------|
| 1 | RED | BLACK |
| 2 | BLACK | WHITE |
| 3 | WHITE | RED |

WIRING DIAGRAM EXPERT PN110 #891-00001 Rev.08





WIRING DIAGRAM

EXPERT PN110

#891-00001 Rev.08