


Temperature Controller

EXPERT SERIES 2 BASIC

USER'S MANUAL



NOTICE

Every effort has been made to ensure that this manual is complete, accurate and up-to-date. The information contained in it is however subject to change without notice due to further developments.

TABLE OF CONTENTS

1. INTRODUCTION	6
1.1 Precautions	6
1.2 Symbols of the Manual	6
1.3 Controller's Overview	7
2. MOUNTING INSTRUCTIONS	10
2.1 Installing the Controller on the Wall	10
2.2 Connections	10
2.2.1 Main Wiring	10
2.2.2 Alarm Connection	10
2.2.3 Sensor Inputs	10
2.2.4 0-10V Output Connection	10
3. USER INTERFACE	11
3.1 Location of the Controls	11
3.2 Parameter Adjustment	12
3.3 LED Meaning	13
4. INSTALLATION SETUP	14
4.1 Setting the Time & Date	14
4.2 Password	15
4.3 Controller Programs	16
4.3.1 Selecting a Program	16
4.3.2 Automatic Program Switch	17
4.3.3 Copying & Pasting Programs	17
4.4 Measuring Units	18
4.5 Installation Setup	19
4.6 RH Compensation Setup	23
4.7 Probe Setup	24
4.7.1 Probe Activation	24
4.7.2 Probe & Water Meter Calibration	25
4.7.3 Probe Assignment	26
4.8 Relay Assignment	27
4.8.1 Assigning Relays to the Outputs	27
4.8.2 Assigning Min.Ventilation Relays	28
4.9 Variable Output Assignment	28
4.10 Night Settings	29
4.11 Clean Mode	30
4.12 Test Mode	31
4.13 Version	31

5	TEMPERATURE SETTINGS	32
5.1	Temperature Set Point	32
5.2	Temperature Curve	33
5.2.1	Principle of Operation	33
5.2.2	Settings	33
5.2.3	Modifying Curve Points	34
6.	VENTILATION & COOLING	35
6.1	Minimum Ventilation	35
6.1.1	Minimum Ventilation Cycles	35
6.1.2	Minimum Speed Curve	37
6.1.3	Modifying Curve Points	38
6.2	Fan Stages	39
6.2.1	Principle of Operation	39
6.2.1.1	Operation of Fan Stages	39
6.2.1.2	Operation of Variable Outputs	39
6.2.1.3	Stage 1 Ramping	41
6.2.2	Fan Stage Settings	42
6.2.3	0-10V Ventilation Outputs	43
6.3	Natural Ventilation Curtains	44
6.3.1	Principle of Operation	44
6.3.2	Natural Ventilation Settings	45
6.3.3	Curtain Compensation	46
6.3.4	Stopping Fans in Natural Vent.	46
6.3.5	Purge	47
6.4	Tunnel Doors	48
6.5	Timer-based Air Inlets	50
6.5.1	Principle of Operation	50
6.5.2	Timer-based Inlet Settings	52
6.5.3	Resetting the Actuator's Position	53
6.6	Air Inlets with Potentiometer	54
6.6.1	Principle of Operation	54
6.6.2	Potentiometer Inlet Settings	55
6.6.3	Inlet Calibration	56
6.7	0-10V Air Inlets	57
6.8	Cool Cells	58
6.9	Misting Output	59
6.10	Stir Fans	61
7.	HEATING	63
7.1	Heating Stages	63
7.2	Heat Lamps (0-10V)	64
7.3	Heat Mats (0-10V)	65

8. LIGHTS	66
9. CLOCK OUTPUTS	66
10. RH COMPENSATION	68
11. SOAKING	70
12. ALARMS	71
12.1 Alarm Log	71
12.2 Alarm Conditions	72
12.3 Alarm Settings	73
13. MONITORING FUNCTIONS	74
13.1 Current Conditions	74
13.2 Run Time Histories	74
13.3 History Menus	75
13.4 Animal Age & Count	76
13.5 Automatic Reminder	77
14. TECHNICAL SPECIFICATIONS	78
15. MEMORY CARD	79
16. WORK SHEETS	81
16.1 Relay Assignment Template	82
16.2 Probe Assignment Template	85
16.3 Installation Setup Template	85
INDEX	86

1. INTRODUCTION

1.1 Precautions

We strongly recommend installing supplementary natural ventilation as well as a backup thermostat on at least one cooling stage (refer to the relay panels' wiring diagram to connect the thermostat).

Although fuses at the input and outputs of the controller protect its circuits in case of an overload or overvoltage, we recommend installing an additional protection device on the controller's supply circuit.

The room temperature where the controller is located **MUST ALWAYS REMAIN BETWEEN 32°F AND 104°F (0°C TO 40°C)**.

To avoid exposing the controller to harmful gases or excessive humidity, it is preferable to install it in a corridor.

**DO NOT SPRAY WATER
ON THE CONTROLLER!**

1.2 Symbols of the Manual



Caution. Read the following text carefully. It contains important pieces of information which, if ignored, may cause the controller to operate improperly.



Pay attention. The following text contains very useful information.



Press the main menu push-button.



Press the proper menu selector.

1.3 Controller's Overview

The EXPERT SERIES 2 BASIC is an electronic device used for environmental control in livestock buildings. It combines sidewall, natural and tunnel ventilation into one powerful system.

The EXPERT SERIES 2 BASIC can control the following inputs and outputs:

OUTPUTS:

20 built-in relays &

16 optional relays to control:

- 3 heating stages;
- 12 fan stages;
- 2 tunnel doors;
- 2 natural ventilation curtains;
- 2 inlet actuators;
- 1 stir fan output;
- 2 clock outputs;
- 1 misting output;
- 1 cool cell output;
- 1 soaking output;
- 1 light output;
- 4 feeders;
- 1 backup relay;

2 built-in 0-10V outputs to control additional fans, heat mats, heat lamps or inlets;

2 built-in variable speed outputs.

INPUTS:

- 8 inside temperature sensors;
- 2 outside temperature sensors;
- 1 inside humidity sensor;
- 1 outside humidity sensor;
- 1 static pressure probe;
- 1 water meter.



Refer to the wiring diagram enclosed at the end of this manual to connect sensors and loads.

MAIN FEATURES:

VERY LARGE LCD DISPLAY

A large LCD screen provides an efficient interface for displaying, monitoring and adjusting the parameters.

3 CONTROLLER PROGRAMS

The controller allows using 3 different programs to control the room temperature. It is thus possible to activate a specific program, that uses particular temperature settings, in accordance with the animal age for instance.

STATUS LEDS

Pilot lights that indicate the status of the controller outputs are located on the faceplate of the controller. These LEDs allow monitoring the system's operation without having to enter the building.

MINIMUM VENTILATION CYCLE

When ventilation is not required to reduce the room temperature, the fan outputs can run either continuously or intermittently to reduce humidity levels and supply oxygen to the room.

8 INDOOR TEMPERATURE SENSORS

Up to eight temperature sensors can be connected to the controller to obtain an accurate reading of the average room temperature and a faster reaction time.

NATURAL VENTILATION CURTAINS

The controller can open 2 natural ventilation curtains and stop all ventilation when the outside temperature is sufficiently warm.

TUNNEL VENTILATION

When the room temperature rises, tunnel ventilation reduces the actual temperature perceived by the animals.

HUMIDITY CONTROL

The inside and outside relative humidity sensors allow controlling humidity levels in the room.

0-10V OUTPUTS

Two 0-10V outputs can be used to control additional variable fan stages, heating devices, and/or inlets.

CONTROL OF THE AIR INLET MOVEMENT

The movement of air inlets can be coordinated with the operation of the fans using a potentiometer located on the panel drive or a timer. This allows the air inlets to be adjusted correctly, without the influence of uncontrollable factors such as wind or air from adjoining rooms

HISTORY MENUS

History menus allow monitoring the sensor readings and verify the run time of some outputs. The controller comes with the following histories menus:

- **Minimum and maximum sensor readings:**
Room temperature 60 days
Inside temperature sensors 10 days
Outside temperature sensor ... 75 days
Inside humidity sensor 75 days
Outside humidity sensor 75 days
Static pressure sensor 75 days
- **Run time of each heater** 75 days
- **Run time of each feeder** 75 days
- **Daily water consumption** 75 days

ALARM MANAGEMENT

The controller provides alarms for high-low temperatures, defective sensors and other system failures. It keeps in memory the 20 most recent alarm conditions.

PASSWORD PROTECTION

A password can be enabled to restrict access to the setup functions of the controller.

BACKUP BATTERY

A backup battery allows the unit to keep time in case of a power failure.

OVERLOAD AND OVERVOLTAGE PROTECTION

Resettable fuses are provided at low-voltage inputs of the controller to protect its circuitry in the case of an overload or overvoltage.

COMPUTER CONTROL

The controller can be connected to a computer, thus making it possible to centralize the management of information and diversify control strategies.

TEST MODE

A test mode allows you to simulate temperature changes and verify controller performances.

2. MOUNTING INSTRUCTIONS

2.1 Installing the Controller on the Wall

Fasten the four metal brackets on the mounting holes located behind the controller using the four screws included with the controller. Mount the enclosure on the wall using four other screws. The enclosure must be mounted in a location that will allow the cover to be completely opened right up against the wall.

2.2 Connections

2.2.1 Main Wiring

Refer to the wiring diagram enclosed with this user's manual to connect the controller. Drill holes at the bottom of the enclosure to pass the wires and install watertight connectors to prevent water from entering in the enclosure. Do not make any holes at the side and top of the enclosure.



ALL WIRING MUST BE DONE BY AN AUTHORIZED ELECTRICIAN AND MUST COMPLY WITH APPLICABLE CODES, LAWS AND REGULATIONS. MAKE SURE POWER IS OFF BEFORE DOING ANY WIRING TO AVOID ELECTRICAL SHOCKS AND EQUIPMENT DAMAGE.

2.2.2 Alarm Connection

There are two types of alarms on the market. One type activates when current is cut off at its input; the other type of alarm activates when current is supplied at its input. For an alarm of the first type, use the NC terminal as shown on the wiring diagram. For an alarm of the second type, use the NO terminal.

2.2.3 Sensor Inputs

Sensors operate at low voltage and are isolated from the supply. Make sure that sensor cables remain isolated from all high voltage sources. In particular, do not route the sensor cables through the same electrical knockout as other cables. Do not connect the shield from the sensor cable to a terminal or a ground.

Extending a sensor:

Each sensor can be extended up to 500 feet (150 meters).

To extend a sensor:

Use a shielded cable of outside diameter between 0.245 and 0.260 in (6.22 and 6.60 mm) (the cable dimensions should not be under 18 AWG) to ensure the cable entry is liquid tight. **Do not ground the shielding.**

It is preferable to solder the cable joint to ensure a proper contact between the two cables.



Do not run sensor cables next to other power cables. When crossing over other cables, cross at 90°.

Defective sensors:


An alarm is generated when a defective sensor is detected. Defective sensors are identified in the "Alarm Log" menu. Refer to chapter 12 for further information on the alarms.

2.2.4 0-10V Output Connection

It is recommended to use a 18 to 22 AWG wire to connect the devices to the 0-10V outputs. This type of output can be used to connect various devices such as heat mats or fans.

3. USER INTERFACE


3.1 Location of the Controls



- Menu selectors**
 Use these buttons to select a menu.
- Main menu short-cut key**
 This short-cut key provides access to the main menu and allows seeing the current status of each input and output on the main screen. The main menu is automatically selected after 4 minutes of inactivity.
- Navigation buttons**
 Use these buttons to select an item displayed in the main screen. In addition, the left and right-arrow key are also used to move through the display by pages (left = page-up, right = page-down).
- Adjustment buttons**
 Use these buttons (+ or -) to modify the value of the selected parameter.

EXPERT SERIES 2 BASIC

- **Back**
Press BACK to return to the previous menu.
- **Main LCD Screen**
The large LCD screen is used to display the various parameters and menus. The contrast of the screen can be adjusted using the potentiometer located behind the display. Open the front panel to access the potentiometer (see picture on the right).
- **LED Display**
This display shows the current reading of chosen sensor(s). Refer to section 4.5 to select what information needs to be shown on the LED display.
- **Status Leds**
Status pilot lights indicate the current status of the outputs. Refer to section 3.3 for further information about these LEDs.
- **Backlight button**
Press this button to light up the LCD screen.



3.2 Parameter Adjustment

Use the navigation buttons to select the desired parameter on the main screen. A parameter that can be modified blinks when it is selected; non-blinking parameters cannot be changed.

EXPERT SERIES 2 BASIC



3.3 LED Meaning

LED		MEANING	
CLEAN MODE		Solid LED:	Clean mode is active.
ALARM		Solid LED:	An alarm condition is active. A corrective action is required.
		Flashing LED:	An alarm condition occurred but no longer exists.
STIR FAN		Solid LED:	the stir fan output is active.
TUNNEL 2	Open	Solid LED:	tunnel door #2 is opening.
	Close	Solid LED:	tunnel door #2 is closing.
TUNNEL 1	Open	Solid LED:	tunnel door #1 is opening.
	Close	Solid LED:	tunnel door #1 is closing.
CURTAIN 2	Open	Solid LED:	natural ventilation curtain #2 is opening.
	Close	Solid LED:	natural ventilation curtain #2 is closing.
CURTAIN 1	Open	Solid LED:	natural ventilation curtain #1 is opening.
	Close	Solid LED:	natural ventilation curtain #1 is closing.
INLET 2	Open	Solid LED:	inlet #2 is opening.
		Flashing LED:	the controller opens inlet #2 to reset the actuator's position.
	Close	Solid LED:	inlet #2 is closing.
		Flashing LED:	the controller closes inlet #2 to reset the actuator's position.
INLET 1	Open	Solid LED:	inlet #1 is opening.
		Flashing LED:	the controller opens inlet #1 to reset the actuator's position.
	Close	Solid LED:	inlet #1 is closing.
		Flashing LED:	the controller closes inlet #1 to reset the actuator's position.
STAGES 1-12		Solid LED:	fan stage #x is active.
MINIMUM VENTILATION		Solid LED:	On Time of the minimum ventilation timer.
		Flashing LED:	Off Time of the minimum ventilation timer.
HEATERS 1-3		Solid LED:	heating output #x is active.
MISTING		Solid LED:	On Time of the misting timer.
		Flashing LED:	Off Time of the misting timer.
SOAKING		Solid LED:	On Time of the soaking timer.
		Flashing LED:	Off Time of the soaking timer.
COOL CELL		Solid LED:	On Time of the cool cell timer.
		Flashing LED:	Off Time of the cool cell timer.
0-10V 1-2		Solid LED:	0-10V output #x is active.
CLOCK 1-2		Solid LED:	clock output #x is active.


4. INSTALLATION SETUP

4.1 Setting the Time & Date

Select:

-  Main menu
 -  Time / Date
-

- Press the right-arrow key once. The current day of the week flashes on the display.
- Use the adjustment buttons to adjust the day of the week.
- Press the right-arrow key to step to the next parameter.
- Proceed in similar fashion to set the whole time and date.



4.2 Password

The controller has three levels of password access:

User 1 password [1-1-1-1]

This password provides access to temperature set points, minimum ventilation settings and to the animal count menu. If many password levels are used, the controller automatically selects this user level after 15 minutes of inactivity.

User 2 [2-2-2-2]

This password provides access to all menus except for installation setup menus. This password can be modified as explained below.

Installer password [0-6-1-0]

This password provides access to all functions of the controller. It can be modified as explained below.

Using passwords is optional. Refer to the Installation Setup section of this manual to enable or disable passwords (section 4.5).

Default installer password

0 - 6 - 1 - 0

User 1 Password





1 - 1 - 1 - 1

User 2 Password


2 - 2 - 2 - 2

ENTERING / CHANGING THE PASSWORD:

Select:

-  Main menu
-  Setup *
-  User
-  Password

* A password may be required to access this menu.



- Use the adjustment buttons to set the first number of the password then press the right-arrow key. Proceed the same way to enter all numbers of the password then press the right-arrow key. The user is then identified.
- If the installation password or user 2 password is posted, the prompt “**Change Password**” appears on screen. Use the adjustment buttons to set the new password code.



IMPORTANT

Choose an easy-to-remember password and write it down in a safe place!

- Use the adjustment buttons to confirm the new installer password then press the right-arrow key to confirm the new password.

4.3 Controller Programs

Program definition

Programs are an assembly of settings (temperature settings, relay assignment, probe assignment, etc.) that can be enabled at different moment of the breeding process. In all, the controller can use 3 different programs.

Automatic program selection

The controller can automatically switch the program selection when the animals reach a certain age or as a function of outside temperature. Refer to the Installation Setup section of this manual to enable or disable the automatic program switch (see section 4.5).



Refer to the Installation Setup section of this manual to set the number of programs in use and to enable or disable the automatic program switch (section 4.5).

Program selection



When a program is selected, all parameter settings that are displayed on screen are related to the chosen program




Make sure the proper program is selected before adjusting any parameter.

4.3.1 Selecting a Program

Select:

-  Main menu
-  Program Selection



- One of these two messages is displayed:

Show settings of:

Even when a program is running you can still display parameter settings of other programs without changing the program in use. Select the desired program to be displayed.

Only programs that are enabled in the Installation Setup are available (see sec. 4.5).

Running program:

This message is shown when the program selection is made manually. Select the running program.




Only programs that are enabled in the Installation Setup are available (see sec. 4.5).

EXPERT SERIES 2 BASIC


4.3.2 Automatic Program Switch

The controller can automatically switch the program selection when the animals reach a certain age or as a function of outside temperature. If the automatic program switch option is enabled in the Installation setup, you must indicate when each program starts.

Select:

-  Main menu
-  Setup*
-  Program

* A password may be required to access this menu (sec. 4.2).



Main menu

Setup

Program

Program Settings

Program 2 above day: 10

Program 3 above day: 20

[OR]

Program 2 above Out T: 50.0

Program 3 above Out T: 75.0

Use ▼ to navigate

- Select the day at which programs 2 and 3 start or select the animal age at which these programs start (depending if the program switch is based on the outside temperature or on the animal age). Program 1 is used when the animal age (or outside temperature) is lower than the start age (or temperature) of programs 2 and 3.






The day number refers to the animal age.


4.3.3 Copying & Pasting Programs

Use the copy-paste function to duplicate all parameter settings associated to a program onto another program. This avoids repeating the same programming sequence several times.

Select:

-  Main menu
-  Setup*
-  Copy/Paste

* A password may be required to access this menu (sec. 4.2).



Main menu

Setup

Copy/paste

Program Settings

Copy From: Program 1

Copy to: Program 2

Confirm? No


Use ▼ to navigate


- **Copy From:**
Select the source program. The one that will be duplicated.
- **Copy to:**
Select the target program. The one on which the copied program will be pasted.
- Once a different source and target programs are selected, the message "**Confirm?**" is displayed. Select "**Yes**" to start the program duplication. The message "**Copy in progress**" is displayed. Wait until the data transfer is over.


4.4 Measuring Units


Select the measuring units as follows:

Select:

 Main menu

 Setup*

 User

 Units

* A password may be required to access this menu (sec. 4.2).

- Select the proper measuring units:

Time display

AM/PM / 24 hours.

Temperature units


Celsius (Deg C) or Fahrenheit (Deg F).

Water

Gallons / Liters.

Static Pressure

Inches of water ("WC) or Pascal (Pa).







Measuring units are common to all programs of the controller.

4.5 Installation Setup

The following section shows how to customize the controller for your particular application. This section explains how to enable and set the outputs of your controller. Normally, this setup needs to be done only once.

Select:

-  Main menu
-  Setup*
-  User
-  Installation

* A password may be required to access this menu (sec. 4.2).



Hint: use the right and left arrow key to move up and down through the display by pages.

- Set the following parameters:

Number of feeders

The controller has 4 inputs that are used to monitor the run time of feeder motors. Enable the proper number of feeder inputs (0 to 4 feeders).

Number of heating stages

Enable the proper number of heating stages (0 to 3 heating stages).


Number of fan stages

Enable the proper number of fan stages (1 to 12 fan stages).

The number of fan stages is limited by the stage number that signals the beginning of tunnel ventilation. Refer to section 6.4 to select the first tunnel stage.

Number of clock outputs

Enable the proper number of clock outputs (0 to 2 clock outputs).



Number of clock cycles

If clock outputs are enabled, select how many timers (cycles) each output uses (1 to 12 cycles).

Number of 0-10V outputs

Enable the proper number of 0-10V outputs (0 to 2 outputs).

Number of natural ventilation curtains

Enable the proper number of natural ventilation curtains (0 to 2 curtains).

Number of tunnel doors

Enable the proper number of tunnel doors (0 to 2 tunnel doors).

0-10V type

Select the type of signal used by each 0-10V output (0-10V or 10-0V).

*Accessible if 0-10V outputs are enabled above.
[This parameter is common to all programs].*

EXPERT SERIES 2 BASIC

0-10V mode

Select the function of each 0-10V output.

Accessible if 0-10V outputs are enabled above.

[This parameter is common to all programs].

- 0-10V ventilation output

When it is used for ventilation, the 0-10V output acts as a fan stage and uses independent temperature settings.

- 0-10V heat mat

When it is used to control heat mats, the 0-10V output is activated at its maximum intensity when the temperature of chosen probes falls below the start temperature of the output.

- 0-10V heat lamp

When it is used to control heat lamps, the 0-10V output starts running at its minimum intensity when the temperature of specific probes falls below the start temperature of the output. The intensity of the heat lamp output increases gradually as the temperature decreases.

- 0-10V inlet

When it is used as an air inlet, the 0-10V opens and closes an actuator as a function of the ventilation level.

0-10V output follows set point

Operating temperatures of 0-10V outputs can either be related to the set point – which means the controller automatically adjusts them when the set point changes – or they can be set as absolute values. Select “Yes” if they follow the set point or select “No” if they set as absolute values. Set this parameter separately for each 0-10V output.


Accessible if 0-10V outputs are enabled above.

[This parameter is common to all programs].

Close inlets in natural

Select “Yes” for inlets to close when the controller enters in natural ventilation.

Accessible if natural ventilation curtains and vent inlets are enabled.



Curtain Compensation

Select “Yes” to enable a compensation on the opening of natural ventilation curtains as a function of the outside temperature.

Accessible if natural ventilation curtains are enabled above and if an outside temperature sensor is enabled in section 4.7.1.

Whisker switch

Whisker switches are used to tell the controller when natural ventilation curtains are sufficiently opened. Select “Yes” to enable the whisker switch input of each curtain or select “No” if these switches are not used.

[This parameter is common to all programs].

Purge

The purge function allows opening natural ventilation curtains on a short period of time to purge the air continuously. Select “Yes” to enable this function.

Variable fan outputs (Ramping)

Select “V1” to enable variable output 1; Select “V1-V2” to enable var. outputs 1 & 2; Select “None” to disable variable outputs (if variable fans are not used, the controller will automatically ramp up the fan speed of stage 1 to make a smooth transition between minimum ventilation cycles and fan stage 1).

EXPERT SERIES 2 BASIC

Inlet

The controller can control two air inlets. Enable the proper number of inlets.

Inlet mode

Inlet #1 can either operate in timer mode or according to a potentiometer. Select "Pot" to use a potentiometer or select "Timer". Note that the second inlet can only operate in timer mode.

Accessible if an inlet output is enabled above.

[This parameter is common to all programs].

Misting

The controller can control one misting output. Select "Yes" to enable this output.

Misting output follows the set point

Operating temperatures of the misting output can either be related to the set point – which means the controller automatically adjusts them when the set point changes – or they can be set as absolute values. Select "Yes" if they follow the set point or select "No" if they set as absolute values.

Accessible if the misting output is enabled above.

[This parameter is common to all programs].

Cool cells

The controller can control one cool cell output. Select "Yes" to enable this output.

Stir fans

The controller can control one stir fan output. Select "Yes" to enable this output.

Soaking

The controller can control one soaking output. Select "Yes" to enable this output.

Lights

The controller can control one light output. Select "Yes" to enable this output.

The screenshot shows a menu titled 'Installation' with a list of settings. The settings are organized into two columns. The first column lists the settings, and the second column shows the current values. The settings are: Inlet Mode (Pot), Use Misting? (Yes), Mist Follow Set Point? (Yes), Use Cool Cell? (Yes), Use Stir Fan? (Yes), Use Soaking? (Yes), Use Light? (Yes), Use Backup Relay (Yes), Use RP-16 (Yes), V1 Min Speed % (20), V1 Motor Curve (4), V2 Min Speed % (20), V2 Motor Curve (4), Use Age? (Yes), Use Temperature Curves? (Yes), Use Min Speed Curves? (Yes), and Number of Programs (3). At the bottom of the menu, it says 'Use ▼ to navigate'.

Setting	Value
Inlet Mode	Pot
Use Misting?	Yes
Mist Follow Set Point?	Yes
Use Cool Cell?	Yes
Use Stir Fan?	Yes
Use Soaking?	Yes
Use Light?	Yes
Use Backup Relay	Yes
Use RP-16	Yes
V1 Min Speed %	20
V1 Motor Curve	4
V2 Min Speed %	20
V2 Motor Curve	4
Use Age?	Yes
Use Temperature Curves?	Yes
Use Min Speed Curves?	Yes
Number of Programs	3

Backup relay

The controller can control one backup relay. Select "Yes" to use a backup relay.

[This parameter is common to all programs].

Use RP-16

Select "Yes" if an external relay panel (RP-16) is connected to the controller.

[This parameter is common to all programs].

V1-V2 Minimum speeds

Set the absolute minimum speed of both variable outputs (V1 & V2).

Accessible if variable outputs are enabled above.

[This parameter is common to all programs].

V1-V2 Motor curves

The relationship between the voltage supplied to a motor and its operating speed is described by a motor curve. This curve varies with the make and capacity of the motor. The various motors available in the industry have been divided into ten categories and the controller has been programmed with a different motor curve for each of these categories. Select the proper motor curve to ensure that the controller supplies the correct voltages according to the type of fan motors used (refer to the motor curve table on the back of the controller's installation guide).

Use age-based functions ?

Some functions of the controller are based on the age of the animals (temperature curve, minimum speed curve & programs). Select "Yes" to use age-based functions or select "No" to disable them.

[This parameter is common to all programs].

Temperature curve

The temperature curve is used to change the temperature set point over time. Select "Yes" to use this curve.

Accessible if age-based functions are enabled above.

[This parameter is common to all programs].

Minimum speed curve

The minimum speed curve is used to change minimum ventilation rate over time. Select "Yes" to use this curve.

Accessible if age-based functions are enabled above.

[This parameter is common to all programs].

Number of programs

The controller can use several temperature programs. Enable the desired number of programs (1 to 3 programs)

[This parameter is common to all programs].


Switch program

The controller can automatically enable a new program when animals reach a certain age or as a function of outside temperature. Specify what factor causes a change in the program selection: "Age" or "Out T" . Select "Manu" if you do not want the controller to change the program.

- Enabling the "Age" factor automatically activates the "Use Age" parameter above;

- Enabling the "Outside Temp." factor automatically enables the outside temperature probe input.

[This parameter is common to all programs].



Use password?

Select "Yes" to enable the password or select "No" to disable it.

[This parameter is common to all programs].

Clear alarms?

Select "Yes" to reset the alarm log.

[This parameter is common to all programs].

Clear Relay Assignment ?

Select "Yes" to clear the assignment between relays and outputs of all programs.

Digit display

Select what piece of information must be shown on the red LED display:

Temp.only:

Temperature only;

Temp/Inlet 1:

Temperature + position of inlet 1.

Temp/Inlet 2:

Temperature + position of inlet 2.

Temp/Inlet 1/Inlet 2:


Temperature + position of inlets 1 & 2

[This parameter is common to all programs].


4.6 RH Compensation Setup

The controller offers different ways to compensate for high and low relative humidity (RH) levels in the barn. This section shows how to enable the desired RH compensation functions.


Select:




Main menu



Setup*



User




RH Compens**

* A password may be required to access this menu (sec. 4.2).

** Accessible if a humidity sensor is enabled (sec. 4.7.1)

- Enable or disable the following relative humidity (RH) compensation options:



The following parameters are common to all programs of the controller.


RH compensation on minimum ventilation?

The controller can compensate for high humidity levels by enhancing the minimum ventilation rate. Select “Yes” to use this compensation method.

Accessible if variable outputs are enabled the Installation Setup (sec. 4.5).

RH compensation with heaters

The controller can compensate for high humidity levels by activating heating outputs in timer mode. Select “Yes” to use this compensation method.



Mist Shutoff

The controller can deactivate the misting output when humidity levels are too high. Select “Yes” to use this compensation method.

Misting on low humidity levels (% RH)

The controller can activate misting outputs when humidity levels are too low. Select “Yes” to use this compensation method.

Cool cell shutoff





The controller can deactivate the cool cell output when humidity levels are too high. Select “Yes” to use this compensation method.

4.7 Probe Setup

4.7.1 Probe Activation

Follow these steps to enable or disable the probe inputs.

Select:

-  Main menu
-  Setup*
-  User
-  Probes

* A password may be required to access this menu (sec. 4.2).

- Enable or disable the following probe inputs:



The following parameters are common to all programs of the controller.

Inside probe


Select the number of inside temperature probes that are connected to the controller (1 to 8 probes).

Inside relative humidity (RH) probe

Select "Yes" if an indoor humidity probe is connected to the controller.

Outside relative humidity (RH) probe

Select "Yes" if an outdoor humidity probe is connected to the controller.



Water meter

Select "Yes" if a water meter is connected to the controller.

Outside T°

Select the number of outside temperature probes that are connected to the controller (0 to 2 probes).

Static pressure (SP) probe





Select "Yes" if a static pressure sensor is connected to the controller.

EXPERT SERIES 2 BASIC

4.7.2 Probe & Water Meter Calibration

You can slightly adjust the reading of each probe input in order to obtain accurate and uniform readings from all probes. In addition, if a water meter is used, you must calibrate its water flow rate.

Select:

-  Main menu
-  Setup*
-  User
-  Prb Calib

* A password may be required to access this menu (sec. 4.2).

- Adjust the reading of the probes (if required):




The probe calibration is common to all programs of the controller.

Temperature probes (indoor & outdoor)

The reading of inside and outside temperature probes can be adjusted of $\pm 3^{\circ}\text{F}$ ($\pm 1.7^{\circ}\text{C}$).

Relative humidity probe

The reading of inside and outside humidity probes can be adjusted of $\pm 3\%$.



Static pressure probe

The reading of the static pressure probe can be adjusted of $\pm 0.030''\text{WC}$ ($\pm 7\text{Pa}$).

Water meter calibration

Enter the flow rate of the water meter. This rate can be adjusted from 1 to 100 gallons (or liters) per pulse.

4.7.3 Probe Assignment

Cooling and heating outputs either run according to the room temperature or according to the average reading of chosen temperature probes.

Room Temperature Sensors

Most cooling outputs of the controller (misting output, tunnel fans, stir fans, etc.) operate according to the average temperature in the room. The user must choose what temperature probes are used to measure this room temperature.

Probe Set 2

Settings

This section explain how to select temperature probes that are used to measure the room temperature and how to assign temperature probes that are used to control/ monitor the following outputs:

- Heaters 1-3
- 0-10V outputs
- Natural ventilation curtains



A template is available at the end of this manual to write down your selection of sensors.

Heater 1 Probe Assignment				
1 ---	2 ---	3 ---	4 ---	5 ---
6 ---	7 ---	8 ---		

The selection of probes that is used to measure the room temperature can be changed in tunnel ventilation to compensate for changes in airflow patterns that can distort the room temperature calculation. If the second probe set is enabled in the Installation Setup (sec. 4.5), you must assign temperature probes to this second probe set.

Select:

- Main menu
- Setup*
- Probe Assignment
- Select the desired output **:
 - Room;
 - Room Set 2;
 - Heaters 1-3;
 - 0-10V outputs 1-2;
 - Natural ventilation curtain 1-2.

* A password may be required to access this menu (sec. 4.2).

** Only outputs that are enabled in the Setup menu are displayed (sec. 4.5).





- Assign the desired temperature probes to the selected output: select "✓" to assign a probe or select " - - " for probes that are not assigned to the output.

4.8 Relay Assignment

4.8.1 Assigning Relays to the Outputs


You must assign On/Off relays to each output of the controller. Use provided output stickers to identify the function of each relay on the faceplate of the controller.

Select:

-  Main menu
-  Setup*
-  Relay Assignment
-  Select the desired output ** :

* A password may be required to access this menu (sec. 4.2).

** Only outputs that are enabled in the Setup menu are available (sec. 4.5).



- Select a relay then set its status as follows:

- ✓ The relay is assigned to the output;
- The relay is not assigned to the output;
- TMR:** The load connected to the relay will run in timer mode (available on fan stage outputs only).



Relays 21-36 correspond to relays 1-16 of Airstream Relay Panel 16.

- Proceed in similar fashion to assign relays to each output in use:

Fan stages 2-12:

Fan stages can either activate regular on/off relays and/or **timer-based** relays. When a timer-based relay is assigned to a fan stage, the relay runs in timer mode when the fan stage is active. This is useful to operate misting units for instance. To use timer-based relays, set the relay status to "TMR" (see example above).

Tunnel 1-2 / inlet 1-2 / natural curtains 1-2:

Relays 7-8 and relays 15-20 have specially been designed for the connection of actuators. When actuators are connected to these relays, their open and close relays can never be activated at the same time.

Feeding output:

Feeder relays are used to stop feeders when a feeder run time alarm occurs. These normally closed relays open when the alarm condition is detected.

Accessible if the feeder alarm condition is enabled (section 12.3).

Backup relay:

The backup relay box relay is a normally closed relay which opens in case of a power failure.

Shutoff fans in natural ventilation:

It is possible to shutoff some fan output when the controller enters in natural ventilation (on/off fans and variable fans). Refer to the natural ventilation section of this manual to get further information about this feature.

Heating stages 1-3;

Misting output;

Soaking output;

Cool cell output;

Clock outputs 1-2;

Stir fan output;

Light output.






A template is available at the end of this manual to write down the function of each relay.

EXPERT SERIES 2 BASIC

4.8.2 Assigning Min.Ventilation Relays

This procedure shows how to assign on/off relays to minimum ventilation cycles. Chosen relays will switch during the “On Time” portion of minimum ventilation cycles. Refer to section 6.8 for further information about minimum ventilation cycles.

Select:

-  Main menu
-  Min. Vent.
-  MinV Relays*

* Accessible the “Minimum Ventilation Relay status” option is enabled in section 6.1.1. A password may also be required to access this menu (section 4.2).

Main menu				
Min. Vent.				
Min.V Relay				
Min Vent. Relay Assignment				
1	2	3	4	5
---	---	---	---	---
6	7	8	9	10
---	---	---	---	---
11	12	13	14	15
---	---	---	---	---
16	17	18	19	20
---	---	---	---	---
Use ▼ to navigate				

- Set the status of each relay: select “√” if the relay is used in minimum ventilation or select “- - -” if it is not.






Relays 21-36 correspond to relays 1-16 of Airstream Relay Panel 16.

4.9 Variable Output Assignment

Two variable outputs can be used to provide variable-speed ventilation. If these outputs are used, you must assign them to the proper fan stages.

Select:

-  Main menu
-  Setup*
-  Variables**

* A password may be required to access this menu (sec. 4.2).

** Accessible if variable outputs are enabled (sec. 4.5).

Main menu			
Setup			
Variable			
Fan Variable Assignment			
Fan Stage 1	Variable 1	Var	
	Variable 2	Var	
Fan Stage 2	Variable 1	On	
	Variable 2	On	
Fan Stage 3	Variable 1	Off	
	Variable 2	Off	
Fan Stage 4	Variable 1	Off	
	Variable 2	Off	

- Set the output status separately for each fan stage in use:

Var: The variable fan output is assigned to the fan stage and operates in **variable mode**: when the stage starts, the variable fan starts running at its minimum intensity. The fan intensity gradually increases as the room temperature increases.

On: The variable fan output is assigned to the fan stage and operates in **on/off mode**: the fan runs at 100% when the fan stage is on and stops when the stage is off.

Off: The variable output is not assigned.




If the last fan stage uses a variable output, the output must use the on/off operating mode. **DO NOT** set the operating mode of the last fan stage to the variable mode.


4.10 Night Settings

Night functions allow changing the target room temperature and the minimum ventilation level when the night comes (refer to the Minimum Ventilation chapter of this manual to set the night fan speed).


Select:




Main menu



Setup*



User



Day/Night

* A password may be required to access this menu (sec. 4.2).

- Set the following parameters:

Night Set Point?

Select “Yes” to use a different target temperature at night; select “No” to disable this function.


Night Minimum Ventilation?

Select “Yes” to change the minimum ventilation fan speed at night; select “No” to disable this function.

Day Time

Set the time at which day settings start being used.

Accessible if a night function is enabled above.



Night Time

Set the time at which night settings start being used.

Accessible if a night function is enabled above.

Transition

If the night set point is enabled above, a transition is made from one set point to the other. Set this transition time to the desired value.

4.11 Clean Mode

The clean mode is used to interrupt regular operations of the controller when the room is empty. When this mode is enabled, the controller simply provides a minimum level of heat and a minimum level of ventilation (optional). While the clean mode is enabled, the letters “CLn” are shown on the LED display.

Cleaning the room




A soaking output can be activated to clean up the room. If this output is used, soaking cycles automatically start when the clean mode is on. Refer to chapter 11 of this manual to get further information about the soaking output.

Clean mode set point

In clean mode, fans that are used to provide minimum ventilation and heaters operate according to the clean mode set point: heaters turn on when the room temperature is lower than the clean mode set point and fans turn on when the temperature is higher than the set point. Refer to section 5.1 to adjust the clean mode set point.

Low temperature alarm

The controller can sound an alarm if the temperature gets too low while the controller is in clean mode. Refer to section 12.3 to set this alarm limit.

Select:	
	Main menu
	Setup *
	Clean Mode

* A password may be required to access this menu (sec. 4.2).

- Enable the desired clean mode options:

Clean mode status


Select “On” to enable the clean mode; select “Off” to disable it.

Use minimum ventilation?

Select “Yes” to activate minimum ventilation cycles while the clean mode is on.

Detect low temperature?

Select “Yes” to enable the low temperature alarm limit or select “No” to disable this alarm condition.



4.12 Test Mode

The test mode is used to simulate temperature changes and to verify the controller’s performances. When the test is enabled, all outputs of the controller operate according to the simulated temperature.


Select:

Main menu

Setup*

Test Mode

* A password may be required to access this menu (sec. 4.2).



- First, set the simulated temperature to the desired value then set the test mode status to “On” to start the test.



The test automatically ends after 15 minutes of inactivity. It can also end sooner by switching the test mode status back to “Off”.

4.13 Version

This menu shows the version number of your controller program. This piece of information is useful to get technical support.

Select:


Main menu

Setup*

User

Version

* A password may be required to access this menu (sec. 4.2).





5 TEMPERATURE SETTINGS

5.1 Temperature Set Point

The set point is a target temperature in the room. The activation of most outputs of the controller is based on this reference temperature.

Select:

-  Main menu
-  Set Point

- The following set points are displayed:



Set point settings are common to all programs of the controller.

Main menu	
Set Points	
Temp Curve	Set Points
Set Points	
Current	75.5 °F
Day	70.0 °F
Night	75.5 °F
Clean Mode	35.0 °F
Outside	75.0 °F
Use ▼ to navigate ▼	

Current set point

This is the current temperature set point in use. This value cannot be changed; to modify the set point, change the day or night set points below.

Day set point

Set the temperature set point that is used during the day (this set point is used all day long if the night set point is not enabled). The controller can also change the day set point automatically over time by using a curve (see section 5.2).

This parameter can only be modified while the temperature curve is inactive (sec. 5.2).

Night set point

A different temperature set point can be used at night. The night set point can be used to lower the target room temperature for instance. The night set point is relative to

the day set point, which means that it is automatically adjusted when the day set point changes. Set the night set point to the desired value.

Accessible if the night set point is enabled (see section 4.10)

Clean mode set point

Select what is the target room temperature while the controller operates in clean mode.

Outside set point

The controller can adjust the moving speed of natural ventilation curtains as a function of outside temperature. When this function is used, the controller refers to the outside temperature set point to control the moving speed. Set the outside temperature to the desired value.

Accessible if the outside temperature sensor is enabled in section 4.7.1 and if the curtain compensation is enabled in the Installation Setup (section 4.5).

5.2 Temperature Curve

5.2.1 Principle of Operation


The controller can automatically adjust the target room temperature (day set point) over time by using a curve.

A curve is composed of 10 steps. Each step specifies a day number and a temperature set point for that day (the day number refers to the animal age). Once the curve is activated, the controller changes the set point every hour in a linear fashion between consecutive steps of the curve. When the last step is reached, the controller keeps using the temperature set point associated to that day.

Notes

Certain restrictions apply to reduce the risk of errors:

- The highest possible day number is 450.
- Decreasing day numbers is not allowed.
- All ten steps must be specified. If you don't need ten different steps, repeat the last temperature for each unnecessary step.



5.2.2 Settings

Select:

- ★ Main menu
- ⏮ Set Point
- ⏮ Temp Curve*

* A password may be required to access this menu.

Cur. Day	Set Point	0 day
day 1	78.0 °F	
day 10	75.0 °F	
day 15	70.0 °F	
day 20	65.0 °F	
day 25	63.0 °F	
day 30	61.0 °F	
day 35	60.0 °F	
day 40	60.0 °F	
day 45	60.0 °F	
day 50	60.0 °F	
Status	Off	

Use ▼ to navigate



The following parameters can only be modified while the curve is off.

If the curve is running, it is still possible to adjust the set point value of all curve steps simultaneously with the curve offset parameter (see sec. 5.1.3).

- Set the following parameters:

Current day

This is the current age of the animals. This value may be changed to move backward or forward on the curve. A change in the current day also changes the animal age in the "Age & mortality" menu.

Set point

The day set point is displayed.

Day numbers

Set the day at which each step starts. The day number refers to the animal age. It is adjustable from -5 to 450 days. Negative values are used to prepare the house before letting the animals enter.

Can only be modified while the curve is disabled.

Temperature set points

Assign a temperature set point to each step of the curve.

Can only be modified while the curve is disabled or by using the curve offset function (sec. 6.1.3).

Status


Select "Yes" to activate the curve. Once the curve is on, the controller automatically adjusts the set point automatically between consecutive points of the curve; for this reason, curve steps cannot be modified while the curve is running.

5.2.3 Modifying Curve Points

You can adjust the temperature set point associated to all curve points while the curve is running.

Select:

- ★ Main menu
- D Set Point
- D Temp Curve
- D Add/Subs Temp*



* Accessible while the curve is running only.

Temperature curve offset

Select the number of degrees that need to be removed or added to all set points of the temperature curve (+/- 10°F).

Accessible if the temperature curve is currently running.

6. VENTILATION & COOLING

6.1 Minimum Ventilation


6.1.1 Minimum Ventilation Cycles

Definition

Minimum ventilation cycles are activated when the average room temperature is below the start temperature of fan stage 1. Running the fans even though ventilation is not required for reducing the room temperature is useful to reduce humidity levels and supply oxygen to the room. It also prevents the fans from freezing in winter.

Minimum ventilation timer

The minimum ventilation timer is composed of an "On Time" and of a "Cycle Time". The fans stay on during the "On Time" then stop until the end of the cycle. This timer is common to all programs of the controller.



Minimum ventilation fans

If variable outputs are enabled, minimum ventilation cycles are ensured by the variable-speed fans of stage 1 and by chosen On/Off fans (optional). If variable outputs are not used, minimum ventilation is ensured by On/Off fans only. Refer to section 4.8.2 to assign these On/Off fans and refer to section 4.9 to assign variable fans to stage 1.

Automatic adjustment of the min. ventilation rate

The controller can automatically increase minimum ventilation rates over time: if variable fans are used, the controller can increase the minimum ventilation fan speed over time (curve function); if no variable fan is used, the controller can increase the "On Time" portion of minimum ventilation cycles (ramping function). Refer to the following sections to use the ramping or the curve function.

Night fan speed

If the nighttime minimum ventilation function is enabled (section 4.10), you can select another minimum ventilation fan speed which will be used at night.

Minimum Ventilation Settings

Select:




Main menu



Min. Vent.

- Set the following parameters:



Variable 1-2 minimum ventilation speed

Specify the minimum ventilation speed of each variable fan; this is the speed of the fans during the “On Time” portion of minimum ventilation cycles. The minimum ventilation speed cannot be set to lower value than the absolute minimum speed of the variable output (as defined in section 4.5).

Accessible if variable fans are assigned to stage 1. In addition, this parameter can only be modified while the speed curve is inactive (sec. 6.1.2.2).

Variable 1-2 status

Set the status of each variable output: select “On” if the output is used in minimum ventilation; select “Off” if it is not.

Accessible if variable fans are assigned to stage 1. In addition, this parameter can only be modified while the speed curve is inactive (sec. 6.1.2.2).

Relay status

Set the relay status to “On” if some On/Off relays need to be activated during the “On Time” portion of minimum ventilation cycles. Refer to section 4.8.2 to assign On/Off fan relays.

Accessible if variable fans are assigned to stage 1: if no variable outputs are used in minimum ventilation, this parameter is automatically enabled and does not appear on screen.

Minimum ventilation timer

Set the “On Time” and the “Cycle Time” of the minimum ventilation timer. The “Cycle Time” must last longer than the “On Time”. This timer is common to all programs of the controller.

This parameter can only be modified while the speed curve is inactive (sec. 6.1.2.2).

6.1.2 Minimum Speed Curve


If variable outputs are assigned to stage 1, the controller can automatically adjust the minimum ventilation speed of these fans over time by using a curve.

A curve is composed of 10 steps. Each step specifies a day number and a minimum ventilation speed for that day (the day number refers to the animal age). Once the curve is activated, the controller changes the minimum ventilation speed every hour in a linear fashion between consecutive steps of the curve. When the last step is reached, the controller keeps using the speed associated to that day.

Notes

Certain restrictions apply to reduce the risk of errors:

- The highest possible day number is 450.
- Decreasing day numbers is not allowed.
- All ten steps must be specified. If you don't need 10 different steps, repeat the last speed for each unnecessary step.
- This curve must be set separately for each program.



Curve Settings

Select:

- Main menu
- Min. Vent.
- Var 1 Curve or Var 2 Curve*

* A password may be required to access this menu (sec. 4.2).

Cur. Day	Min Speed	0 day
day 1	20	%
day 10	22	%
day 15	24	%
day 20	26	%
day 25	28	%
day 30	30	%
day 35	35	%
day 40	40	%
day 45	45	%
day 50	50	%
Status	Off	

Use ▼ to navigate



The following parameters can only be modified while the curve is disabled.

If the curve is running, it is still possible to adjust the value of all curve steps simultaneously with the curve offset parameter (see section 6.1.3).

- Set the following parameters separately for each variable output in use:
(Refer to the previous section to get further information on these parameters)

Current day

This is the current age of the animals. This value may be changed to move backward or forward on the curve. A change in the current day also changes the animal age in the "Age & mortality" menu.

EXPERT SERIES 2 BASIC

Minimum Speed

The current minimum ventilation speed of the selected fan output is displayed.

Day numbers

Set the day at which each step starts. The day number refers to the animal age and it is adjustable from -5 to 450 days. Negative values are used to prepare the house before letting the animals enter.

Can only be modified while the curve is disabled.

Speed

Assign a fan speed to each step of the curve.

Can only be modified while the curve is disabled.





Status

Select "Yes" to activate the curve. Once the curve is on, the controller automatically adjusts the minimum ventilation speed automatically between consecutive points of the curve; for this reason, curve steps cannot be modified while the curve is running.


6.1.3 Modifying Curve Points

You can adjust the speed associated to all curve points while the curve is running.

Select:

-  Main menu
 -  Min. Vent.
 -  Var1 or Var 2 Curve
 -  Add/Subs Speed*
-

** Accessible while the curve is running only.*



Var 1 & 2 min. speed curve offset

Select the speed that needs to be removed or added to all steps of the minimum speed curve (+/- 10%). Set this parameter separately for the curve of variable output 1 and 2.


Accessible if the minimum speed curve is currently running.

6.2 Fan Stages

6.2.1 Principle of Operation

6.2.1.1 Operation of Fan Stages

The controller has 12 fan stages which operate in a sequence to increase the level of ventilation as the room temperature increases. Each stage can activate two variable outputs, on/off outputs, and a combination of timer relays for cooling purposes. A fan stage is activated when the room temperature reaches its start temperature and is disabled when the room temperature decreases to its stop temperature.




Start temperatures of fan stages are defined with respect to the set point and with respect to each other. This means that when one of these values is adjusted, all the consecutive values are adjusted by the same amount. For example, if the set point is increased by 1 °F, the start temperature of all fan stages will be increased by the same amount.

Timer-based relays in fan stages

Fan stages can activate relays that operate following a timer (On and Off Times). This is useful to activate misting units in timer mode while a specific fan stage is active. Refer to section 4.8 to enable timer-based relays.

6.2.1.2 Operation of Variable Outputs

Variable outputs are activated when their associated fan stage starts (see section 4.9). They start running at their absolute minimum speed (see section 4.5) and their speed gradually increases as the room temperature increases. Variable outputs reach their full speed when the start temperature of the following fan stage is reached.




EXPERT SERIES 2 BASIC

Transition between fan stages 1 and 2

If the next stage is an on/off fan stage, variable outputs are deactivated at the start-up of the stage; if the next stage is another variable-speed stage, the speed of variable outputs is reduced to minimum at the start-up of the second variable stage. This ensures a smooth transition between both stages. The following graphic shows this.

Initial speed of variable outputs:

Variable outputs of fan stages 1 & 2 start at the same speed as the fan speed used in minimum ventilation (sec. 6.1.1).



The **bandwidth** is the temperature interval over which variable outputs go from their minimum to their maximum speed. This is true even if full speed is never reached as in the example above: when stage 2 starts, the controller decreases the speed of variable outputs to their minimum speed. The controller then uses the bandwidth to increase the fan speed as the room temperature rises.

EXPERT SERIES 2 BASIC

6.2.1.3 Stage 1 Ramping


The controller can gradually increase (or decrease) the running time of the fans to smooth out the transition from the minimum ventilation cycle to full operation of stage 1 fans.

At room temperatures at or below the set point, the controller operates the fans of stage 1 according to the minimum ventilation cycle.

If the room temperature rises above the set point, a new On Time is calculated periodically as the temperature increases to allow a smooth progression

(from point A to point B) up to full operation of the fans when the set point + differential 1 is reached (when Time Off becomes less than 15 seconds, it is fixed at 15 seconds until the temperature has reached the set point + differential 1. At that point, the fans of stage 1 operate continuously).

If the room temperature decreases 0.3°F below the set point + differential 1, the On Time value of the minimum ventilation cycle decreases gradually from a value equal to the total cycle time (point C) towards the regular On Time.





Ramping Settings


To use the ramping function, disable variable outputs in the Installation Setup (section 4.5) and adjust the differential of stage 1 in section 6.2.2.

6.2.2 Fan Stage Settings

Select:

 Main menu

 Start/Stop*

 Fan Stages

* A password may be required to access this menu (sec. 4.2).

- Set the following parameters:
(Refer to the previous section to get further information on these parameters)

Start & Stop temperatures

Set the start and stop temperatures of each fan stage.

Notes:

Stage 1 stops when the room temperature falls 0.3 °F below its start temperature.


The minimum difference between two consecutive start temperatures is of 0.5 °F (0.3 °C).

The start temperature of a fan stage must be greater value than its stop temperature.


V1 & V2 Bdw (Bandwidth)

The bandwidth is the temperature interval over which variable outputs go from their minimum to their maximum speed. Set the bandwidth of each variable output in use.

Accessible if variable outputs are assigned to fan stages (section 4.9).



Fan Stage		Start	Stop
Stage 1	Start	70.0 °F	
	V1 Bdw	2.0 °F	
	V2 Bdw	2.0 °F	
	Differential	2.0 °F	
Stage 2	Start	72.0 °F	
	Stop	71.0 °F	
Stage 3	Start	74.0 °F	
	Stop	73.0 °F	
Stage 4	Start	76.0 °F	
	Stop	75.0 °F	
Stage 5	Start	78.0 °F	
	Stop		

Use  to navigate

Differential

The differential is the temperature difference between the moment the Stage 1 start running in timer mode (stage 1 ramping) and the moment they run continuously. Refer to the diagram in section 6.2.1.3 The differential can be adjusted between 0.5°F and 20.0°F (0.3°C and 11.1°C).

Accessible if the ramping option is enabled (i.e. if variable outputs are disabled in the Installation Setup (section 4.5)).


Timer

If timer-based relays are assigned to some fan stages (sec. 4.8), set the On Time and the Off Time of each timer-based relay. On and Off Times can be adjusted from 0 to 99 minutes in increments of 15 seconds.

6.2.3 0-10V Ventilation Outputs

The controller has two 0-10V outputs that can either be used to control heat lamps, heat mats, inlets or fans. To operate these outputs, the controller refers to the average temperature reading of their assigned temperature probes (see sec. 4.7.3).

This section explains how 0-10V ventilation outputs work.



0-10V ventilation outputs start at their minimum intensity when the average temperature of their probes reaches the start temperature. They increase in intensity as the temperature increases; 0-10V outputs reach their maximum intensity when the temperature rises to the Maximum Temperature parameter setting.

0-10V Mode: Automatic / Manual

You can manually control the intensity of a 0-10V output by using the manual control mode. While this mode is used, the controller stops controlling the output and lets you choose the intensity of the output.

Main menu	
Start/Stop	
0-10V	
0-10V #X	
0-10V Output #X Ventilation	
Mode	Automatic
Current Output	100 %
Start Temperature	70.0 °F
Minimum	40
Maximum	100
Max Output at	72.0 °F
Stop at	69.5 °F

Settings

Select:

- Main menu
- Start/Stop*
- 0-10V**
- Select a 0-10V **Ventilation** output**

* A password may be required to access this menu.

** Accessible if a 0-10V ventilation output is enabled in the Installation Setup (section 4.5).

- Set the following parameters:

Mode: Set the operating mode of the 0-10V output: select "Automatic" if you want the controller to control the output or select "Manual" to specify the intensity of the output yourself.

Current output: This is the current intensity of the output. This intensity can be modified while the manual mode is enabled above.

Start temperature: Set the start temperature to the desired value. This temperature can be set as a fix value (absolute) or it can be related to the set point: this means that when the set point changes, the start temperature is adjusted by the same amount. (refer to section 4.5 to specify if the start temperature of the 0-10V follows the set point or not).

Minimum & max speeds: Set the minimum and maximum speeds of the 0-10V output. The maximum speed must be greater than the minimum speed.

Maximum output at: Set the temperature at which the output reaches its maximum speed (this parameter must be set to a greater value than the start temperature).

Stop at: This is the temperature below which the 0-10V output stops.

6.3 Natural Ventilation Curtains

The controller can control two natural ventilation curtains. To operate these curtains, the controller refers to the average temperature reading of their assigned temperature probes (see sec. 4.7.3).

6.3.1 Principle of Operation

The controller enters in natural ventilation when the average temperature of the probes that are assigned to a curtain reaches the *Initial Opening Temperature* of the curtain. At that moment, the curtain opens during its *Initial Opening Time*.

When the natural ventilation mode is on, the natural ventilation curtain moves in timer mode: it opens according to its opening cycle (*Open Time & Off Time*) when the average temperature rises above its opening temperature; likewise, it closes according to its closing cycle (*Close Time & Off Time*) when the temperature falls below its closing temperature.


Natural ventilation is disabled when the average temperature decreases of 5°F (2.8°C) below the curtain's closing temperature or when tunnel ventilation starts (see graph below).

Transition from tunnel to natural ventilation

When the temperature decreases below the start temperature of the first tunnel stage, the controller opens the curtain continuously during the *Continuous Opening Delay*. When this delay has elapsed, it starts controlling the curtain using natural ventilation settings.





Transition from natural to tunnel ventilation

When the natural ventilation curtain is opened and the room temperature reaches the start temperature of the first tunnel stage, the controller waits for the *Tunnel Close Delay* then fully closes the natural ventilation curtain.



6.3.2 Natural Ventilation Settings

Select:

-  Main menu
-  Start/Stop*
-  Natural**
-  Curtain #X

* A password may be required to access this menu (sec. 4.2).

** Accessible if at least 1 natural ventilation curtain is enabled in the Installation Setup (section 4.5).

- Set the following parameters:
(Refer to previous sections to get further information on these parameters)

Initial Open at

Set the temperature at which the curtain opens for the first time. The curtain opens during its initial moving time at that moment.

Start Close at

Set the temperature below which the curtain starts closing in timer mode when the controller is in natural ventilation.

Start Open at


Set the temperature above which the curtain opens according to a timer when the controller is in natural ventilation.

Initial Time

The curtain opens during its initial opening time when the controller enters in natural ventilation. This opening time can be adjusted from 0 to 900 seconds (15 minutes).

Open / Close / Off Time

Set the opening and closing timers of the curtain (the Off time is common to both cycles). The open, close and off times can be adjusted from 0 to 900 seconds (15 minutes).



Wind Delay When the controller is in natural ventilation and temperature falls below the "Start Close At" temperature or rises above the "Start Open At" temperature, the curtain only starts moving after the wind delay has elapsed. This way, the curtain does not move when wind drafts cause sudden temperature changes. Set the wind delay to the desired value. Adjustable from 0 to 900 seconds (15 minutes).

Tunnel Close Delay (Factory Setting)

This delay is launched at the beginning of the first tunnel stage. Once it has elapsed, the controller closes the natural ventilation curtain.

Continuous Delay (Factory Setting)

The natural ventilation curtain opens during this delay when the controller returns in natural ventilation (when tunnel ventilation ends).

Purge Move Time

This is the amount of time required to open the curtain during a purge cycle (see sec. 6.3.5). Set this parameter separately for each curtain.


Accessible if the purge option is enabled in the Installation Setup (section 4.5).

6.3.3 Curtain Compensation

The controller can slightly adjust opening of the curtains as a function of outside temperature: as the outside temperature increases, the controller increases the opening time of the curtains. As a result, curtains open faster when the outside temperature gets warm. Likewise, when the outside temperature gets cold the controller increases the closing time of the curtains. This compensation is optional. To use it, enable the curtain compensation in the Installation Setup (section 4.5). Then, set the outside temperature set point (section 5.1).


When temperature rises:

When the curtain opens, the controller increases the curtain's On Time by 4% for every 1°F (0.6°C) in the compensation interval (i.e. an interval of 3°F means a 12% increase). The curtain's Off Time is decreased by the same amount.



When temperature falls:

When the curtain closes, the controller increases the curtain's On Time by 4% for every 1°F (0.6°C) in the compensation interval (i.e. an interval of 3°F means a 12% increase). The curtain's Off Time is decreased by the same amount.



6.3.4 Stopping Fans in Natural Vent.


Whisker switches are used to stop some on/off and variable-speed fan outputs when the controller is in natural ventilation. These switches tell when the curtains are sufficiently opened.

When temperature rises (point A on the graphic):

The controller gradually opens the curtain as temperature rises. It can also disable a chosen selection of fans when the curtain is sufficiently opened (when the curtain has reached its whisker switch).

When temperature falls (point B on the graphic):

At point B, the curtain is already opened and the fans are stopped. The controller gradually closes the curtain as temperature falls. The controller restarts the fans when the curtain closes and releases its whisker switch.



Security: If the temperature drops suddenly or if the whisker switch is defective, the controller automatically restarts the fans when the temperature falls 5°F (3°C) below the lowest curtain's closing temperature. When this situation occurs, a defective whisker switch alarm is posted to the alarm log.



Refer to section 4.8 to select what fan relays must turn off in natural ventilation.

6.3.5 Purge


The purge function allows opening natural ventilation curtains on a short period of time to purge the air continuously.

Principle of operation

When a purge cycle starts, both curtains open during their respective *Purge Move Time*. They then stay still during the *Purge Time*. When this delay has elapsed, both curtains return to their initial position until the beginning of the next purge cycle.

Frequency of the purge cycles

The frequency of purge cycles is determined by the *Purge Cycle Time*. A new purge cycle time after that time delay has elapsed.







Purge cycles are not performed while the controller is in tunnel ventilation.



Refer to section 6.3.2 to set the amount of time each curtain need to open during a purge cycle (Purge Move Time).

Settings

Select:


-  Main menu
-  Start/Stop*
-  Natural**
-  Purge***

* A password may be required to access this menu.

** Accessible if at least 1 natural ventilation curtain is enabled in the Installation Setup (section 4.5).

*** Accessible if the purge option is enabled in the Installation Setup (section 4.5).

- Set the following parameters:



Purge Time

Once they are opened, curtains stay still during this amount of time before returning to their initial position. Set the purge time to the desired value.

Purge Cycle

This is the amount of time that separates two purge cycles. The cycle includes the *Purge Move Time* (sec. 6.3.2) and the *Purge Time*. Set the purge cycle time to the desired value.

6.4 Tunnel Doors

The controller can control 2 tunnel doors. It opens these doors gradually as the room temperature increases.

Beginning of tunnel ventilation

The activation of tunnel ventilation is linked with the activation of a user-defined fan stage: when the start temperature of that chosen fan stage is reached, the tunnel door opens during the opening time associated with that stage. The activation of every consecutive fan stages causes the tunnel door to open further. The stage at which the tunnel door fully opens is also defined by the user.

Minimum age

A minimum age can be specified to avoid entering in tunnel ventilation when the animals are too young. This feature is optional and can only be used if age-based functions are enabled in the Installation Setup (section 4.5).

Minimum outside temperature


A minimum outside temperature can be specified to avoid entering in tunnel ventilation when it is too cold outside. This feature is optional and can only be used if an outside temperature probe is enabled (sec. 4.7.1).

Opening times

The user must associate an opening of the tunnel door to each tunnel fan stage. When a tunnel fan stage starts, tunnel doors open according to the opening time associated to that stage. Opening times are set separately for each tunnel door.




Reference temperature in tunnel ventilation

The selection of probes that is used to measure the room temperature can be changed in tunnel ventilation to compensate for changes in airflow patterns that can distort the room temperature calculation. The user must select at what fan stage the second probe set starts being used.



Tunnel door Settings

Select:

-  Main menu
-  Start/Stop*
-  Tunnel**

* A password may be required to access this menu.

** Accessible if at least one tunnel door is enabled in the Installation Setup (section 4.5)

- Set the following parameters:
(Refer to the previous section to get further information on these parameters)

First stage

Both tunnel doors start opening when the start temperature of this fan stage is reached. Select what fan stage signals the beginning of tunnel ventilation.

100 % opened

Both tunnel doors fully open when the selected fan stage starts. Select the fan stage at which tunnel doors are totally opened.


Probe set 2 starts at stage

Select at what fan stage the controller starts measuring the room temperature with the second probe set.

Closing inlets

Select the fan stage at which inlets must close.

This menu is only available if inlets are not closed in natural ventilation (see Installation Setup in section 4.5).



Minimum age

Select the animal age below which both tunnel doors remain closed. Adjustable from 1 to 450 days or select "Off" to disable this function.

Available if age-based functions are enabled in the Installation Setup (section 4.5).

Minimum outdoor temperature

Select the outside below which both tunnel doors remain closed or select "Off" to disable this function.

Available if an outside temperature probe is enabled (section 4.7.1).

Opening times

Assign a tunnel door opening time to the start-up of each tunnel fan stage. If two tunnel doors are used, assign these opening times separately for each tunnel door. Opening times can be adjusted from 0 to 900 seconds (15 minutes).

6.5 Timer-based Air Inlets

The controller can control the opening of two air inlets. It can either control the first inlet in timer mode or with a potentiometer; the second air inlet can only operate in timer mode. Set the operating mode of the first air inlet in the Installation Setup (section 4.5).

6.5.1 Principle of Operation


When timer-based inlets are used, the user must first specify the total time that is required to fully open each inlet. Then, the user must associate an inlet opening with the start-up of each fan stage (inlet openings are defined as a percentage of the total opening time). As the room temperature increases and new stages are activated, air inlets will open or close accordingly.

Inlet opening in minimum ventilation

Inlets are at their "Closed" position during the Off Time portion of minimum ventilation cycles; they open to the position associated with stage 1 during the On Time.

Over-opening of air inlets

A supplementary stage can be defined in order to continue opening air inlets beyond the activation temperature of the last ventilation stage. This over-opening stage is used to direct the airflow more efficiently during periods of warm weather. When all reference points of ventilation stages are defined, the user can specify the temperature at which air inlets reach their over-opening position (Start T° of the last stage + over-opening bandwidth).




Opening of the inlets in a variable-speed fan stage

When variable-speed fan stages are used, the user must associate an inlet opening with the beginning and with the end of each variable stage. Once this is done, it is possible to subdivide this opening into 0 to 2 intermediate opening steps to progressively open the inlet during the stage.

When intermediate opening steps are used, the controller splits up the inlet opening of the variable stage evenly between the number of intermediate steps (e.g., if one intermediate step is enabled, the controller will open the inlet twice during the variable stage (50% of the stage opening at the first intermediary step, 50 % at the end of the stage)).




Inlets open to their intermediate positions when the variable stage reaches predefined fan speeds. These fan speeds are set differently depending on the number of intermediate steps in use. For instance, if 1 intermediate step is enabled, the inlet opens during half of the variable stage's opening when the stage's speed is of 75 %; it reaches the stage's HI opening position when the fan stage reaches 100 %.

The three following graphs illustrate when each intermediate step starts as a function of the number of intermediate steps.



6.5.2 Timer-based Inlet Settings

Select:

-  Main menu
-  Inlets*
-  Inlet 1 is already displayed; press Inlet 2 to display parameter settings of Inlet 2.

* Accessible if at least one inlet is enabled in the Installation Setup (section 4.5). A password may also be required to access this menu (section 4.2).



Make sure you have selected a timer-based air inlet. Refer to section 4.5 to set the inlet mode.



Inlet openings are defined as a percentage of their total opening time.

Position

This is the current position of the selected air inlet. This value cannot be modified.

Test mode

This is the room temperature that is used in test mode. This value can only be modified in the "Test Mode" menu (see section 4.12).

Closed

This is the position of the air inlet during the Off Time portion of minimum ventilation cycles. Set this position to the desired value.

Stage #x

Assign an inlet opening (in %) with each fan stage in use.

Stage #x max

Assign the inlet opening that is reached when the variable-speed fan stage reaches its maximum intensity.

Main menu	
Inlets	
Inlet 1 Settings	
Inlet 2	Position 0 %
Auto Reset	Test Mode 72.3 °F
Openings	
	Closed 0 %
	Stage 1 10 %
	Stage 1 Max 15 %
	Stage 2 20 %
	Stage 3 30 %
	Stage 4 40 %
	Stage 5 50 %
	Stage 6 60 %
	Stage 7 70 %
	Stage 8 80 %
Over Opening settings	
	Opening 100 %
	Bandwidth 5.0 °F
	Total Opening Time 2:00 m:s
	#Step on var. stage 1
Use ▼ to navigate ▼	

Over-Opening Settings:

Opening

Assign an inlet position to the over-opening stage.

Bandwidth

Set the temperature range over which the inlet gradually opens from the position associated with the last fan stage towards the over-opening position (see previous graphic).

Total opening time

Enter the **exact time** that is required to reach the actuator's maximum limit switch. The controller will limit the opening of the inlet according to this parameter value.

* Accessible if at least one timer-based inlet is enabled in the Installation Setup (section 4.5).
[This parameter is common to all programs].

of opening steps in variable stages

Set the number of intermediary steps that are used to open the inlet in the course of a variable-speed fan stage.

* Accessible if at least one timer-based inlet is enabled and if variable outputs are enabled in the Installation Setup (section 4.5).
[This parameter is common to all programs].

6.5.3 Resetting the Actuator's Position

Resetting the actuator's position is used to clear accumulated time offsets caused by the frequent openings and closings of the inlet. The controller resets the actuator's position at regular intervals to make sure the inlet position is always accurate. This reset is performed automatically according to one of these two methods:

- **Reset the minimum position only**
(Close mode)

Each time a reset is performed, the inlet totally closes. Once the actuator's position is reset, the inlet returns to its previous position. The "Close" pilot light of the inlet flashes while the controller closes the inlet.




- **Reset toward the nearest position**
(Open/Close mode)

If the current inlet position is higher than 50% at the reset time, the controller fully opens the inlet to reset the actuator's position; if the current inlet position is lower than 50%, the controller closes the inlet to perform the reset. This way, the inlet never closes when the room temperature already asks for a wide opening. The "Open" or "Close" pilot light of the inlet flashes while the controller moves the inlet.



Make sure limit switches are located at both ends of the actuators when using this resetting method.

Select:

-  Main menu
-  Inlets*
-  Auto-Reset*

* Accessible if at least one timer-based inlet is enabled in the *Installation Setup* (section 4.5). In addition, a password may be required to access this menu.



[The following parameters are common to all programs].

Main menu	
Inlets	
Auto Reset	
Auto Reset Settings	
Inlet Reset Mode	Op/Cl
Inlet Reset Now?	No
Day Time	6:00A h:m
Period	3 day
Reset Delay	2:00 m:s

Inlet reset mode:

Select the desired reset mode: "Op/Cl" to reset the actuator toward its nearest position; select "Close" to reset the actuator toward its closed position only or select "Off" to disable the automatic reset.

Inlet reset now? Select "Yes" to reset the actuator's position now.

Day time:

Set the time at which resets are performed.

Period:

Enter the frequency of inlet resets. A reset can be performed once every 1-7 days.

Reset delay:

During a reset, the controller opens or closes the inlet during this delay, or up until a limit switch is reached. The reset delay should be set to the same time value or higher than the total opening time (as defined in section 6.5.2).

6.6 Air Inlets with Potentiometer

The controller can control the opening of two air inlets. It can either control the first inlet in timer mode or with a potentiometer; the second air inlet can only operate in timer mode. Set the operating mode of the first air inlet in the Installation Setup (section 4.5).

6.6.1 Principle of Operation

When potentiometer-based inlets are used, the user associate an inlet opening with the start-up of each fan stage. As the room temperature increases and new stages are activated, air inlets will open or close accordingly.

Inlet opening in minimum ventilation

The inlet is at its "Closed" position during the Off Time portion of minimum ventilation cycles; it opens to the position associated with stage 1 during the On Time.


Over-opening of the air inlet

A supplementary stage can be programmed in order to continue opening the air inlet beyond the activation temperature of the last ventilation stage. This over-opening stage is used to direct the airflow more efficiently during periods of warm weather. When all reference points of ventilation stages are defined, the user can specify the temperature at which the air inlet reaches its over-opening position (Start T° of the last stage + over-opening bandwidth).



Security function

If the potentiometer is defective, the controller will operate in security mode: if the room temperature is 2°F (1.1 °C) above the set point, the inlet opens according to the following cycle: 8 seconds ON, 60 seconds OFF. If the room temperature is 2°F (1.1 °C) below the set point, the inlet closes according to the same cycle.



6.6.2 Potentiometer Inlet Settings

Select:

 Main menu

 Inlets*

Inlet 1 is already displayed.

* Accessible if at least one inlet is enabled in the Installation Setup (section 4.5). In addition, a password may be required to access this menu (section 4.2).



Make sure inlet 1 uses a potentiometer. Refer to section 4.5 to set the inlet mode. (Note that inlet 2 cannot operate with a potentiometer).

- Set the following parameters:
(Refer to the previous section to get further information on these parameters)

Position

This is the current position of the selected air inlet. This value cannot be modified.

Test mode


This is the room temperature that is used in test mode. This value can only be modified in the “Test Mode” menu (see section 4.12).

Closed

This is the position of the air inlet during the Off Time portion of minimum ventilation cycles. Set this position to the desired value.

Stage #x

Assign an inlet opening (in %) with each fan stage in use.



Stage #x max

Assign the inlet opening that is reached when the variable-speed fan stage reaches its maximum intensity.

Over-Opening Settings:

Opening

Assign an inlet position to the over-opening stage.

Bandwidth

Set the temperature range over which the inlet gradually opens from the position associated with the last fan stage towards the over-opening position (see previous graphic).




6.6.3 Inlet Calibration

If inlet 1 uses a potentiometer, the actuator of the inlet must be calibrated. This calibration tells the controller what are the minimum and maximum positions of the actuator:

Minimum calibrated position = opening of 0%

Maximum calibrated position = opening of 100%


Select:

-  Main menu
-  Inlets *
-  Calib**

* Accessible if at least one inlet is enabled in the Installation Setup (section 4.5). In addition, a password may be required to access this menu.


** Accessible if inlet 1 uses a potentiometer (section 4.5).

- Set the following parameters:
(Refer to the previous section to get further information on these parameters)



Save minimum position?


To calibrate the minimum position, use the "Close" switch to close the inlet to its minimum position. Once the inlet is closed, set the manual control switch to "Off" to stop the actuator.



Now that the actuator is closed, answer "Yes" to the "Save minimum position?" question on screen. Once the "Yes" answer is posted, the controller switches the answer back to "No"; the minimum position is now saved.


Save maximum position?

To calibrate the maximum position, use the "Open" manual control switch to fully open the inlet. Once the maximum inlet opening is reached, set the manual control switch to "Off" to stop the actuator.



Now that the actuator is opened, answer "Yes" to the "Save maximum position?" question on screen. Once the "Yes" answer is posted, the controller switches the answer back to "No"; the maximum position is now saved.

- Once the calibration is completed, set the manual control switch back to the "Auto" position to enable the automatic control of the inlet.



For best results, make sure at least 12 inches (30 cm) separates the minimum actuator's position from its maximum position.

6.7 0-10V Air Inlets

The controller has two 0-10V outputs that can either be used to control heat lamps, heat mats, inlets or fans. To operate these outputs, the controller refers to the average temperature reading of their assigned temperature probes (see sec. 4.7.3). This section shows how a 0-10V inlet output works.





A 0-10V air inlet works exactly the same as a potentiometer-based air inlet but does not need to be calibrated.

0-10V Mode: Automatic / Manual

You can manually control the opening of a 0-10V output by using the manual control mode. While this mode is used, the controller stops controlling the output and lets you choose the inlet opening.


Settings

Select:

-  Main menu
-  Start/Stop*
-  0-10V**
-  Select a 0-10V Air Inlet output**

* A password may be required to access this menu.

** Accessible if a 0-10V inlet output is enabled in the Installation Setup (section 4.5).



- Set the following parameters:



0-10V inlets work as potentiometer-based inlets. Refer to section 6.6.1 to see how they work and to get information about the following parameters.

Mode

Set the operating mode of the 0-10V output: select "Automatic" if you want the controller to control the output according to specified parameter settings below or select "Manual" to specify the inlet opening manually.

Opening

This is the current opening of the air inlet. This opening can be changed when the manual mode is enabled above.

Closed

This is the position of the air inlet during the Off Time portion of minimum ventilation cycles. Set this position to the desired value.

Stage #x

Assign an inlet opening (in %) with each fan stage in use.

Stage #x max

Assign the inlet opening that is reached when the variable-speed fan stage reaches its maximum intensity.

Over-Opening Settings:

Opening

Assign an inlet position to the over-opening stage.

Bandwidth

Set the temperature range over which the inlet gradually opens from the position associated with the last fan stage towards the over-opening position (see graphic in section 6.6.1).

6.8 Cool Cells

The controller can control one cool cell output. This cooling system reduces the air temperature by evaporation of water into the airstream.

Principle of operation

The cool cell output can either operate according to the inside temperature or outside temperature: it starts running in timer mode when the inside (or outside) temperature rises and reaches the output's start temperature; the output stops when temperature falls below a user-defined value. It can also stop when humidity levels are too high (see RH Compensation in chapter 10).

If the cool cell output operates according to the inside temperature, its start and stop temperatures are related to the set point; this means they are automatically adjusted when the set point changes. That is not the case if cool cells operate according to the outside temperature.


Operating time range

The user can specify a time range during which the cool cell output can run. This allows deactivating the output at night for instance.

Cool Cell LED

The Cool Cell LED located on the faceplate of the controller tells the status of cooling cycles:

- LED is Off: Cool cell output is off.
- LED is On: On Time of a cool cell cycle;
- LED blinks: Off Time of a cool cell cycle.




Settings

Select:

- ★ Main menu
- ⏮ Start/Stop*
- ⏮ Cool Cells**

* A password may be required to access this menu.

** Accessible if the cool cell output is enabled in the Installation Setup (section 4.5).



- Set the following parameters:

Temperature: Select "inside" if the operation of cool cells is based on the inside temperature; select "outside" if it is based on the outside temperature.

On temperature: Select the temperature (inside or outside T°) at which the cool cell output starts.

Off temperature: Select the temperature (inside or outside T°) below which the cool cell output stops.

On & Off times: Set the on & off times of the cool cell timer.

Start & stop at: Specify the time range during which the cool cell can run.

6.9 Misting Output

The controller can control one misting output. When the room temperature reaches the start temperature of the output, mist units are activated and run in timer mode according to their minimum timer (*Min On Time & Min Off Time*). Then, as temperature rises, a gradual transition is made from the minimum timer towards the maximum timer (*Max On Time & Max Off Time*). The second mist timer is fully used when the room temperature reaches the *Maximum Temperature* parameter setting. The misting output is disabled when the temperature falls below a user-defined value. It can also stop when humidity levels are too high (see RH Compensation in chapter 10).

Start and stop temperatures of the misting output are related to the set point. This means that when the set point changes, these temperatures are adjusted accordingly.


Operating time range

The user can specify a time range during which the output can run. This allows deactivating the misting output at night for instance.

Mist LED




The Mist LED located on the faceplate of the controller tells the status of misting cycles:

- LED is Off: Mist output is off.
- LED is On: On Time of a misting cycle;
- LED blinks: Off Time of a misting cycle.



Settings

Select:

-  Main menu
-  Start/Stop*
-  Misting **

* A password may be required to access this menu.

** Accessible if the misting output is enabled in the Installation Setup (section 4.5).

- Set the following parameters:

On temperature

Select the temperature at which the misting output starts.

Off temperature

Select the temperature below which the misting output stops.

Minimum On & Off times

Set the on & off times of the minimum misting timer.

Maximum Temperature


Set the temperature at which the maximum misting timer if used.

Maximum On & Off times

Set the on & off times of the maximum misting timer.

Start & stop at

Specify the time range during which the misting output can run.




6.10 Stir Fans

The controller can control one stir fan output. This output can operate in three different ways:


Stir fans used in hot temperature conditions:

If the temperature in the room is too high, stir fans can be enabled to create an air draft to cool down the animals. When they are used for this purpose, stir fans start operating continuously when the room temperature reaches the output's start temperature. The output is disabled when the temperature falls below the output's stop temperature (see graph on the right).




Stir fans used in cold temperature conditions:

When the room temperature is too low, stir fans can be activated to disperse the warm air produced by heating units uniformly throughout the building. When they are used for this purpose, stir fans start running in timer mode when the room temperature falls below the output's start temperature. They are disabled when the room temperature rises and reaches the output's stop temperature (see graph on the right).






Stir fans used to reduce temperature differences between probes

Stir fans can start running in timer mode when there is a considerable temperature difference between the reading of two probes. This function is used to ensure the uniformity of the temperature in the house. When they are used for this purpose, stir fans start running when the difference of temperature between two probes exceeds a user-defined temperature limit; they stop when the temperature difference between the probes gets 0.5 °F (0.3 °C) below the limit (see graph on the right).



Settings

Select:

-  Main menu
-  Start/Stop*
-  Stir Fan**

* A password may be required to access this menu.

** Accessible if the stir fan output is enabled in the Installation Setup (section 4.5).

- Set the following parameters:

Hot temperature

Select "Yes" if you want to use the stir fan output in hot temperature conditions.

Cold temperature


Select "Yes" if you want to use the stir fan output in cold temperature conditions.

Probe differential

Select "Yes" if you want to use the stir fan output to reduce temperature differences between probes.

Hot start temperature

If stir fans are used in hot temperature conditions, set the room temperature at which the output starts.



Cold start temperature

If stir fans are used in cold temperature conditions, set the room temperature below which the output starts.

Probe differential

If stir fans are used to reduce temperature differences between probes, set the maximum allowable temperature difference. The output starts when the difference between two probe readings exceeds this value.

Cold and probe timer


Stir fans operate according to a timer when they are used in cold temperature conditions and when they are used to reduce temperature differences between probes. Set the on and off times of the stir fan timer.

7. HEATING

7.1 Heating Stages

The controller can control three independent heating stages. These stages are independent from one another and each operate according to their own temperature settings and probe selection.





An heating stage starts when the temperature reading of its assigned probes falls below the stage's start temperature. The stage stops when the temperature rises and reaches the stage's stop temperature.



Start and stop temperatures of the heating output are related to the set point. This means that when the set point changes, these temperatures are adjusted accordingly.

Settings

Select:

-  Main menu
-  Settings
-  Start/Stop*
-  Heaters

* A password may be required to access this menu.

- Set the following parameters:

The screenshot shows a menu hierarchy: Main menu > Start/Stop > Heaters. The 'Heaters' menu is open, displaying a table with heater settings. At the bottom, it says 'Use ▼ to navigate'.

Heaters Start / Stop		
Heater 3	On	64.0 °F
Heater 3	Off	66.0 °F
Heater 2	On	66.0 °F
Heater 2	Off	68.0 °F
Heater 1	On	68.0 °F
Heater 1	Off	70.0 °F

On temperature

Set the temperature below which each heating stage starts.


Off temperature

Set the temperature at which each heating stage stops. Note that the *Off Temperature* of an heating stage must be at least 0.5 °F (0.3 °C) higher than its *On Temperature*.

7.2 Heat Lamps (0-10V)

The controller has two 0-10V outputs that can either be used to control heat lamps, heat mats, inlets or fans. To operate these outputs, the controller refers to the average temperature reading of their assigned temperature probes (see sec. 4.7.3). This section explains how 0-10V heat lamps work.

0-10V heat lamps start at their minimum intensity when the temperature falls below the start temperature of the output. The intensity of heat lamps increases as the temperature decreases; the maximum intensity is reached when the temperature falls below the *Max. Temperature* parameter setting.







0-10V Mode: Automatic / Manual

You can manually control the intensity of a 0-10V output by using the manual control mode. While this mode is used, the controller stops controlling the output and lets you choose the intensity of the output.

Settings

Select:

-  Main menu
-  Start/Stop*
-  0-10V**
-  Select a 0-10V **Heat Lamp** output*

* A password may be required to access this menu.

** Accessible if a 0-10V heat lamp output is enabled in the Installation Setup (section 4.5).

Main menu	
Start/Stop	
0-10V	
0-10V #X	
0-10V Output #X Heat Lamp	
Mode	Automatic
Current Output	0 %
Start Temperature	70.6 °F
Minimum	40
Maximum	100
Max Output at	68.6 °F
Stop at	71.1 °F

- Set the following parameters:

Mode: Set the operating mode of the 0-10V output: select "Automatic" if you want the controller to control the output or select "Manual" to specify the intensity of the output yourself.

Current output: This is the current intensity of the output. This intensity can be modified while the manual mode is enabled above.

Start temperature: Set the start temperature to the desired value. Note that this temperature can be set as a fix value (absolute) or it can be related to the set point: this means that when the set point changes, the start temperature is adjusted by the same amount. (refer to section 4.5 to specify if the start temperature of the 0-10V follows the set point or not).


Minimum & max intensities: Set the minimum and maximum intensities of the 0-10V output. The maximum intensity of the output must be greater than the minimum intensity parameter value.

Maximum output at: This is the temperature at which the output reaches its maximum intensity. It must be set to a higher temperature value than the start temperature.

Stop at: This is the temperature below which the output stops.

7.3 Heat Mats (0-10V)

The controller has two 0-10V outputs that can either be used to control heat lamps, heat mats, inlets or fans. To operate these outputs, the controller refers to the average temperature reading of their assigned temperature probes (see sec. 4.7.3). This section explains how a 0-10V heat mat works.







0-10V heat mats starts operating at its full intensity (100%) when the average temperature of chosen sensors reaches the start temperature of the output. It is disabled when the temperature rises 0.5 °F (0.3 °C) above the start temperature.

0-10V Mode: Automatic / Manual

You can manually control the intensity of a 0-10V output by using the manual control mode. While this mode is used, the controller stops controlling the output and lets you choose the intensity of the output.


Settings

Select:

-  Main menu
-  Start/Stop*
-  0-10V**
-  Select a 0-10V **Heat Mat** output*

* A password may be required to access this menu (sec. 4.2).

** Accessible if a 0-10V heat mat output is enabled in the *Installation Setup* (section 4.5).



- Set the following parameters:

Mode: Set the operating mode of the 0-10V output: select “Automatic” if you want the controller to control the output or select “Manual” to specify the intensity of the output yourself.

Current output: This is the current intensity of the output. This intensity can be modified while the manual mode is enabled above.




Start temperature: Set the start temperature to the desired value. Note that this temperature can be set as a fix value (absolute) or it can be related to the set point: this means that when the set point changes, the start temperature is adjusted by the same amount. (refer to section 4.5 to specify if the start temperature of the 0-10V follows the set point or not).

8. LIGHTS

The controller can control one light output. The lights turn on when the *On Time* of a light cycle is reached and turn off at the *Off Time*. In all, you can program up to 5 daily light cycles.


Settings

Select:

-  Main menu
-  Start/Stop*
-  Lights**

* A password may be required to access this menu.

** Accessible if the light output is enabled in the *Installation Setup* (section 4.5).



- Set the following parameters:


On & Off Times:

Set the On and Off times of each lighting cycle to the desired value. If 5 cycles are not required, set the On and Off Times of unused cycles to the same value.

9. CLOCK OUTPUTS





The controller has two outputs to control various devices using the real-time clock. These clock output can use up to 12 timer cycles. Refer to the *Installation Setup* to select the number of timer cycles required (section 4.5).

A clock output starts when the *On Time* of a timer is reached; it either stops after a user-defined running time or at the *Off Time*, depending on chosen option. The following diagrams show both possibilities:



Settings

Select:

-  Main menu
-  Start/Stop*
-  Clocks**
-  Clock #x

* A password may be required to access this menu.
** Accessible if at least 1 clock output is enabled in the Installation Setup (section 4.5).



- Set the following parameters:

Clock mode

The clock mode allows stopping a clock output at a certain time of the day or after a certain run time. Select “Start/Stop” to specify the time at which each cycle starts and stops or select “Start/Run” to specify the running time of each cycle. Note that the “Start/Run” option allows stopping cycles with more precision since this mode allows adjusting the seconds.

On Time / Off Time or Run Time

Set the time at which each cycle starts then set the moment at which each cycle ends.




10. RH COMPENSATION

The controller offers different way to compensate for high/low relative humidity (RH) levels in the room. All compensation functions are explained below. To use them, you must enable each desired compensation function in section 4.6.

- High RH Compensation on the Minimum Ventilation Rate:**


The controller can compensate for high RH levels by enhancing the speed of variable-speed fans in minimum ventilation. When this compensation function is used, the controller adjusts the minimum ventilation rate as a function of indoor RH levels. As humidity levels increase, the controller increases the speed of both variable outputs. The maximum compensated fan speed is reached when indoor humidity levels are 10% above the RH set point.



If 2 variable fans are enabled but only variable fan 1 is used in minimum ventilation, the controller activates variable fan 2 at minimum speed when RH levels are 5% above the RH set point.

- High RH Compensation with Heating Outputs:**

When RH levels are too high, the controller can activate heating outputs in timer mode. As RH levels increase, the controller increases the On Time portion of the heating cycle to compensate for the change. The maximum compensated heating On Time is reached when RH levels are 10% above the RH Set Point.



- High RH compensation with cool cells & misting outputs:**

If RH levels are too high, the controller can stop the misting output and/or cool cell output. These outputs are disabled when RH levels reach the respective RH shutoff limit of each output.



- Low RH compensation with misting outputs:**

To compensate for low RH levels, the controller can activate the misting output in timer mode. The misting output starts when RH levels decrease below the *Low RH Set Point*.

EXPERT SERIES 2 BASIC

Settings

Select:

-  Main menu
-  RH Comp*

* Accessible if at least one RH compensation function is enabled in section 4.6. In addition, a password may be required to access this menu (section 4.2).

Main menu	
RH Comp.	
RH Compensation	
Min Vent. Compens.	30 %
RH Set Point	65 %
Heater Compensation	
Min On Time	15 sec
Max On Time	45 sec
Cycle Time	300 sec
Mist on Low % Humidity	
Low Set Point	Off %
On time	15 sec
Off Time	900 sec
Mist Shutoff	Off %
Cool Cell shutoff	Off %
Use ▼ to navigate	

- Set the following parameters:
(Refer to the previous page to get further information on these parameters)

Minimum ventilation compensation

This is the speed that is added to the regular minimum ventilation fan speed when RH levels are 10% above the RH set point. Set the compensation speed to the desired value or select "Off" to disable this function.


Accessible if RH compensation on minimum ventilation is enabled in section 4.6.

RH Set Point

This is the humidity level above which high RH compensation functions start. Adjustable from 20 to 99% of humidity (select "Off" to disable all high RH comp. functions).

Heater compensation

The timer used by heating outputs is made of an On Time and of a Cycle Time. Heating outputs run during the On Time then stop until the end of the Cycle Time. The On Time portion of this cycle increases as RH levels increase.



Minimum & Maximum On Times

Set the minimum and maximum On Times of the heating timer. The minimum On Time starts being used when indoor humidity levels reach the RH set point; the maximum On Time is used when humidity levels are 10% above the RH set point.

Accessible if RH compensation with heating outputs is enabled in section 4.6.

Cycle Time

Set the cycle time of the heating timer.

Accessible if RH compensation with heating outputs is enabled in section 4.6.

Misting outputs on low humidity levels

Accessible if RH comp. on Low RH levels is enabled in section 4.6.

Low Set Point

Set the humidity level below which misting units start running in timer mode or select "Off" to disable this function.

On & Off Times

Set the On and Off Times of the misting timer.

Mist & Cool Cell Shutoff

Set the humidity level above which the misting output and/or the cool cell output stops or select "Off" to disable this function.




Accessible if the mist shutoff compensation and/or cool cell shutoff option is enabled in sec. 4.6.

11. SOAKING

The controller can control one soaking output to operate cleaning instruments. It automatically activates this output in timer mode when the clean mode starts. The user can also specify the number of soaking cycles that need to be performed or can choose to run these cycles continuously.


Settings

Select:

-  Main menu
-  Start/Stop*
-  Soaking**

* A password may be required to access this menu.

** Accessible if the soaking output is enabled in the Installation Setup (section 4.5).



Soaking Output LED

The Soaking Output LED located on the faceplate of the controller tells the status of soaking cycles:

- LED is Off: Soaking output is off;
- LED is On: On Time of a soaking cycle;
- LED blinks: Off Time of a soaking cycle.

- Set the following parameters:

On & Off Times

The soaking timer is made of an On Time and of an Off Time. The On Time can be adjusted from 0 to 3600 seconds (1 hour); the Off Time can be adjusted from 0 to 240 minutes (4 hours). Set these parameters to the desired values.

of soaking cycles

Select the number of soaking cycles that need to be performed or select "cont." to run these cycles continuously.

12. ALARMS

When an alarm occurs, the controller lights up the alarm pilot light, displays letters “AL” on the LED display, and post the alarm condition into the alarm log menu. Some user-defined alarm conditions may also activate the alarm relay.

The table on the right gives a list of all possible alarm conditions. Refer to section 12.3 to specify which of these alarm conditions must activate the alarm relay.




Another alarm situation occurs when power to the controller fails. In this case, the alarm relay is activated. When the alarm relay is activated, the normally open contact (—●—●—) closes.


Display	Meaning
Low Temp Alarm	Low temperature alarm
High Temp Alarm	High temperature alarm
Low Pressure Alarm	Low static pressure alarm
High Pressure Alarm	High static pressure alarm
Probe #1-8 Defect	A temperature probe is defective
Outside Probe #x Defect	Outside probe #x is defective
Whisker Switch Defect	The Whisker switch is defective
Water Spill	Water consumption too high
SP Probe Defect	The static pressure sensor is defective
Inside RH Probe Defect	The indoor humidity probe is defective
Outside RH Probe Defect	The outdoor humidity probe is defective
Relay panel comm. Error	Communication is disrupted between the controller and the relay panel.
Inlet potentiometer defect	The potentiometer is defective.
Feeder 1-4 run time exceeded	A feeder has been running continuously on a too long period of time.

12.1 Alarm Log

To access the alarm log

Select:

-  Main menu
-  Monitoring
-  Alarms




12.2 Alarm Conditions

Temperature Alarms

The diagram below shows how temperature alarms are detected.

When the average room temperature exceeds the high temperature alarm setting, a high temperature alarm is set off. When the average room temperature decreases below the low temperature alarm setting, a low temperature alarm is set off. Although these settings are entered by the user as absolute values, they are defined based on the room set point. They are thus automatically adjusted if the set point changes.

The situation is slightly different when the outside temperature is greater than the room set point. In this case, the outside temperature becomes the reference point (instead of using the set point as a the reference). This means an alarm is set off when the room temperature reaches Outside Temperature + High Alarm Offset (the offset being the difference between the high alarm temperature setting and the set point). A third parameter, called the critical temperature, is defined to continue monitoring the indoor temperature for high temperatures. When the indoor temperature reaches the critical high temperature (defined as an absolute value), an alarm is set off.



Temperature Alarms in Clean Mode

The controller can monitor low temperature alarms when it is in clean mode. If this alarm condition is used, the controller sounds an alarm when the temperature falls below low alarm limit that is associated to the clean mode.

The low alarm limit used in clean mode is related to the clean mode set point; this means the alarm limit is automatically adjusted when the clean mode set point changes.

Water Spill Alarm

A water spill alarm is set off when the water consumption exceeds a user-defined limit. This limit can be adjusted from 0 to 10,000 gallons or liters per 15 minutes. The alarm is activated if a greater amount of water is consumed within the 15 minute delay.

Static Pressure Alarms




The controller can sound an alarm when the static pressure (SP) level exceeds high or low pressure limits for a certain period of time.

Feeder Alarm


The controller sets off an alarm if a feeder runs continuously on a too long period of time. When this type of alarm occurs, the relay associated with the problematic feeder opens in order to stop the feeder motor. This alarm condition is optional.

12.3 Alarm Settings

Select:

-  Main menu
-  Start/Stop*
-  Alarms

* A password may be required to access this menu (sec. 4.2).



- Set the following alarm limits:
Refer to the previous page to get further information about these parameters).
- **Temperature Alarms**

Clean mode: Set the temperature below which a temperature alarm is set off in clean mode.

Lo/Hi alarm: Set the room temperature below and above which a temperature alarm is set off.

Critical temperature: Set the absolute temperature above which an alarm is set off.
Accessible if an outside temperature probe is enabled (section 4.7.1).

- **Water spill limit**
Specify the maximum amount of water that can be consumed in 15 min (0 to 10,000 gallons or liters/15 min).
Accessible if a water meter is enabled (sec. 4.7.1)
- **Static pressure limit**
Accessible if a SP probe is enabled (section 4.7.1).

Low / High alarm: Set the pressure levels below and above which an alarm is set off.

Delay: The high or low pressure condition must be maintained on this period of time before the controller sets off the alarm. Set the static pressure alarm delay to the desired value (in seconds).

- **Feeder monitoring**
Select "Yes" if you want the controller to monitor the run time of feeding inputs. If this alarm condition is enabled, set the maximum run time of each feeder (in minutes). Refer to section 4.8 to assign the relay that must open in case of a run time alarm.
Accessible if feeders are enabled (section 4.5).
- **T° Probe Difference**
Select "Yes" if you want the controller to sound an alarm if the temperature difference between two probe readings gets too high.
- **T° Difference**
If the temperature probe difference alarm condition is enabled above, specify the temperature difference above which the controller must sound an alarm.
- **Activate the alarm relay:**
Select "Yes" if you want the controller to activate the alarm relay when the following alarm conditions occur:
 - Lo / Hi Temperature
 - Lo / Hi Static pressure
 - Water spill
 - Defective sensors: temperature, humidity, static pressure)
 - Communication error with the RP-16
 - Defective potentiometer
 - Defective whisker switch

[Alarm conditions that activate the alarm relay are common to all programs].

EXPERT SERIES 2 BASIC

13. MONITORING FUNCTIONS

13.1 Current Conditions

The current condition menu gives a quick view of the actual conditions in the barn.

Select:

 Main menu




- The current conditions (inputs and output) are shown on screen. Use the arrow keys to scroll the display.

Main menu	
Set Point	Current conditions
Min. Vent.	Clear Warning 1^ No
	Room Temperature 72.3 °F
Start/Stop	Current Stage 2
	Current Probe Set 1
Inlets	Set Point 70.0 °F
	Inside Humidity Low %
History	Outside Humidity Low %
	Static Pressure .000 "WC
Age/Mortal	Outside T° High °F
	Heating Stages xx
Clean Mode	Clock Output xx
	Inlet 1 Position 0 %
Monitoring	Inlet 2 Position 0 %
	V1 Current Speed 100 %
Program	V2 Current Speed 100 %
Selection	Running Prog: Program 1
	Temperature Probe 1 72.3 °F
Setup	Temperature Probe 2 72.4 °F
	Temperature Probe 3 72.3 °F
Time/Date	Temperature Probe 4 72.1 °F
	Temperature Probe 5 72.3 °F
	Temperature Probe 6 72.4 °F
Use ▼ to navigate	

13.2 Run Time Histories

Monitoring menus contain the daily run time of the following outputs: water meter, feeders & heaters. The controller keeps these daily run times in memory for 75 days and logs these values into monitoring menus at midnight.

Select:





-  Main menu
-  Monitoring
-  Select the desired monitoring menu:
 - Water
 - Feeders
 - Heaters

Main menu	
Monitoring	
Water	
Water Consumption 75 days	
Total	10 Lit
Today	4 Lit
Jan 02 200X	4 Lit
Jan 01 200X	6 Lit
Use ▼ to navigate	

Resetting the run time of a feeder

To reset the run time of a feeder, select the following menus then follow the prompts on screen.

Select:

-  Main menu
-  Monitoring
-  Feeders
-  Reset Feeder

13.3 History Menus

History menus give a daily record of probe readings and of the animal count. These pieces of information are logged into history menus at midnight. Refer to section 13.2 to consult run time histories (for heaters, water consumption and feeders).


Select:

Main menu

History

Select the desired type of history:

- Room temperature**
This menu contains the daily minimum and maximum readings of the room temperature of the past 60 days.
- Probe temperature**
This menu contains the daily minimum and maximum temperature readings of each temperature probe for the past 10 days.
- Outside temperature**
This menu contains the daily minimum and maximum readings of outside temperature probes for the past 75 days.
Accessible if an outside temperature sensor is enabled (section 4.7.1).
- Inside relative humidity (RH)**
This menu contains the daily minimum and maximum inside humidity readings of the past 75 days.
Accessible if the inside humidity sensors is enabled (sec. 4.7.1).



- Outside relative humidity (RH)**
This menu contains the daily minimum and maximum outside humidity readings of the past 75 days.
Accessible if the outside humidity sensors is enabled (sec. 4.7.1).
- Static Pressure**
This menu contains the daily minimum and maximum static pressure readings of the past 75 days.
Accessible if humidity sensors are enabled (sec. 4.7.1).
- Mortality / Culled / Marked**
These menus contain the daily count of mortalities, culled, and of marked animals of the past 75 days.
Accessible if age-based functions are enabled (section 4.5).

13.4 Animal Age & Count

Animal age

Some parameters of the controller can automatically change over time as the animals grow up (curves, programs & tunnel door). Using age-based parameters is optional, refer to section 4.5 to enable or disable the animal age function.

Animal count

(current count / mortality / culled / marked)

At the beginning of a group, the user must specify the initial number of animals. Afterwards, the user can specify the number of mortalities, culled, and marked animals as it occurs.



ALL histories of the controller are reset when a new group starts.

Settings

Select:



Main menu



Age/Mortality*

- Accessible if age-based functions are enabled in the Installation Setup (section 4.5)

Main menu	
Age/Mortal.	
Age & Mortality	
Animal Age	-4 day
Initial Count	1200
Current Count	1200
Start New Group?	No
New Mortality	0
Today's Mortality	0
Total Mortality	0
New Culled	0
Today's Culled	0
Total Culled	0
New Marked	0
Today's Marked	0
Total Marked	0
Use ▼ to navigate ▼	

- Set the following parameters:
- **Animal age**
The animal age can be adjusted from -5 days to 450 days. Negative day values are used to prepare the house before letting the animals in.
- **Initial count**
Enter the initial number of animals in the room before enabling the new group.
- **Current count**
The current count is automatically adjusted as mortalities or culled animals are posted.
- **Starting a new group**
Before starting a new group, enter the animal age and the initial count.



ALL histories of the controller are reset when a new group starts.

- **New mortalities**
Post the number mortalities as mortality occurs. Once it is validated, the parameter value automatically goes back to "0". The posted value is added to the total mortality count and removed from the current animal count.
- **New culled**
Post the number culled animals as it occurs. Once it is validated, the parameter value automatically goes back to "0". The posted value is added to the total culled count and removed from the current animal count.
- **New marked**
Post the number marked animals when new animals are marked. Once it is validated, the parameter value automatically returns to "0". The value is added to the total marked count.




13.5 Automatic Reminder

The controller can display warning messages at regular intervals. The automatic reminder allows you to associate a warning message to a servicing activity for instance then decide the frequency at which this servicing activity must be performed. In all, the controller can display 3 different warning messages.


When a warning message is active, the word "Warning" is displayed on screen, along with the message number.

Settings

Select:

-  Main menu
-  Setup*
-  Warning

* A password may be required to access this menu (sec. 4.2).



- Set the following parameters:

Show warning 1-3 every

Select the frequency at which each warning message is displayed (1 to 450 days); select "Off" to disable a warning message.

Clearing the Warning Message

Select:

-  Main menu

Main menu	
Current Conditions	
Clear Warning 1?	No
Clear Warning 2?	No
Clear Warning 3?	No
Room Temperature	72.3 °F
Current Stage	2
Current Probe	Set 1

Clear Warning #x ?


This menu appears when a warning message is displayed on screen. Select "Yes" to reset the timer of the warning message.



It is suggested to write down the meaning and frequency of warning messages 1-3:


Warning #	Meaning	Frequency
warning 1		every ____ days
warning 2		every ____ days
warning 3		every ____ days

14. TECHNICAL SPECIFICATIONS

Type	EXPERT SERIES 2 BASIC
Main supply fuse F1	 4A, slow-blow
Mains supply/frequency	85-250V, 50/60Hz
0-10V outputs 1-2	0-10Vdc, 30mA source max.
Precision on 0-10V outputs	$\pm 1\%$
14Vdc output	14 VDC $\pm 10\%$, regulated, 250 mA max.
Alarm contact	150 mA, 24 Vac or dc max.
Housing	IP54, plastic casing
Operating temperature	32 to 104°F (0 to 40 °C)
Storage temperature	5 to 122 °F (-15 to 50 °C)
Ambient relative humidity	max. 95%
Pot + output	3.0V, 20 mA max.
Potentiometer inputs	1-20 K pot., linear
RH input	4-20 mA
Outside RH input	0-2.5V DC
Temperature inputs	1K @ 77 °F (25 °C), NTC
Relays 1-20	Dry contact 15 A RES, 50/60 Hz 16 FLA @ 120 VAC (1HP, 746 W) 12 FLA @ 240 VAC (2HP, 1490 W)

15. MEMORY CARD

The memory card is used to create a backup of your controller's program and parameters. The card is also useful to transfer all settings of a controller to another controller of the same type.



Accessing the Transfer Menu




Turn off power each time you open the controller's front panel. This prevents accidental exposure to areas of high voltage.

1. Turn off power to the controller.
2. Unscrew the screws located on the controller's front panel then open the panel.
3. Insert the memory card in the connector located on the electronic board located on the back of the front panel. Position the card as illustrated.
4. Close the front panel then reapply power to the controller. The transfer menu should be shown on screen (if this is not the case, simultaneously press the up- and down-arrow keys for 3 seconds to display this menu).

Select the desired transfer menu:

- ☐ Memory Card → Controller
- or
- ☐ Controller → Memory Card







Memory Card → Controller


The configuration recorded on the memory card is divided into three parts:

1. Controller's software
2. Parameter settings
3. Calibration settings

It is now possible to upload only one of these components without affecting all the others. For instance, you can upload a new software in your controller without affecting your calibration & parameter settings.

- Access the transfer menu as explained on the previous page and select the "Memory Card → Controller" transfer.
- Select the proper configuration file (*.bin) on the main screen.
- Press the button that corresponds to the components you want to load in the controller:

-  Complete (all parts)
-  Software
-  User data (parameter settings)
-  Pot. Calib (inlet calibration settings)




- Once the transfer is over, press Exit. Turn off power then remove the memory card from the connector.

Controller → Memory Card

Follow this procedure to save the whole configuration of your controller on a memory card.

- Access the transfer menu as explained on the previous page and select the "Controller → Memory Card" transfer.
- Press "Complete" to save the controller configuration on the card.



- Once the transfer is over, press Exit. Turn off power then remove the memory card from the connector.

Erasing the Memory Card

Follow this procedure to delete all the content of the memory card.

- Access the transfer menu as explained on the previous page and select the "Controller → Memory Card" transfer.
- Press "Erase card" to delete all files that were saved on the card.
- Once the erasing process is over, press Exit. Turn off power then remove the memory card from the connector.

16. WORK SHEETS

CLIENT

Name: _____

Address: _____

City: _____

Tel.: _____

Fax: _____

E-mail: _____

INSTALLER

Name: _____

Address: _____

City: _____

Tel.: _____

Fax: _____

E-mail: _____

PROGRAM 1

16.1 Relay Assignment Template

		INTERNAL RELAYS 1-20																						16 OUTPUT RELAY PANEL															
Module relay #:		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Corresponds to		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
Heater 3																																							
Heater 2																																							
Heater 1																																							
Mitr. vent. on/off fans																																							
Fan stage 1																																							
Fan stage 2																																							
Fan stage 3																																							
Fan stage 4																																							
Fan stage 5																																							
Fan stage 6																																							
Fan stage 7																																							
Fan stage 8																																							
Fan stage 9																																							
Fan stage 10																																							
Fan stage 11																																							
Fan stage 12																																							
Tunnel door 1 OPN																																							
Tunnel door 1 CLO																																							
Tunnel door 2 OPN																																							
Tunnel door 2 CLO																																							
Inlet 1 OPN																																							
Inlet 1 CLO																																							
Inlet 2 OPN																																							
Inlet 2 CLO																																							
Natural curtain OPN																																							
Natural curtain CLO																																							
Natural curtain OPN																																							
Natural curtain CLO																																							
Stir fans																																							
Feeder relay																																							
Backup relay																																							
Misting																																							
Soaking																																							
Cool cell																																							
Time Clock 1																																							
Time Clock 2																																							
Lights																																							
Module relay #:	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
Corresponds to	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	

PROGRAM2

INTERNAL RELAYS 1-20																										16 OUTPUT RELAY PANEL															
Module relay #:		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
Corresponds to		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36		
Heater 3																																									
Heater 2																																									
Heater 1																																									
Min. vent. on/off fans																																									
Fan stage 1																																									
Fan stage 2																																									
Fan stage 3																																									
Fan stage 4																																									
Fan stage 5																																									
Fan stage 6																																									
Fan stage 7																																									
Fan stage 8																																									
Fan stage 9																																									
Fan stage 10																																									
Fan stage 11																																									
Fan stage 12																																									
Tunnel door 1 OPN																																									
Tunnel door 1 CLO																																									
Tunnel door 2 OPN																																									
Tunnel door 2 CLO																																									
Inlet 1 OPN																																									
Inlet 1 CLO																																									
Inlet 2 OPN																																									
Inlet 2 CLO																																									
Natural curtain OPN																																									
Natural curtain CLO																																									
Natural curtain OPN																																									
Natural curtain CLO																																									
Stir fans																																									
Feeder relay																																									
Backup relay																																									
Misting																																									
Soaking																																									
Cool cell																																									
Time Clock 1																																									
Time Clock 2																																									
Lights																																									
Module relay #:		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16		
Corresponds to		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	V1	V2	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36		

PROGRAM 3

[illegible]

EXPERT SERIES 2 BASIC

16.2 Probe Assignment Template

PROGRAM 1

	PROBES							
Output	1	2	3	4	5	6	7	8
Heater 3								
Heater 2								
Heater 1								
Room T°								
Probe set 2								
0-10V #1								
0-10V #2								
Natural curtain 1								
Natural curtain 2								

PROGRAM 2

	PROBES							
Output	1	2	3	4	5	6	7	8
Heater 3								
Heater 2								
Heater 1								
Room T°								
Probe set 2								
0-10V #1								
0-10V #2								
Natural curtain 1								
Natural curtain 2								

PROGRAM 3

	PROBES							
Output	1	2	3	4	5	6	7	8
Heater 3								
Heater 2								
Heater 1								
Room T°								
Probe set 2								
0-10V #1								
0-10V #2								
Natural curtain 1								
Natural curtain 2								

16.3 Installation Setup Template

	INSTALLATION SETUP		
	Program 1	Program 2	Program 3
# feeders	____ (0-4)	____ (0-4)	____ (0-4)
# heating stages	____ (0-3)	____ (0-3)	____ (0-3)
# fan stages	____ (1-12)	____ (1-12)	____ (1-12)
# clock output	____ (0-2)	____ (0-2)	____ (0-2)
# 0-10V outputs	____ (0-2)	____ (0-2)	____ (0-2)
# natural ventilation curtains	____ (0-2)	____ (0-2)	____ (0-2)
# tunnel doors	____ (0-2)	____ (0-2)	____ (0-2)
0-10V 1 signal	<input type="checkbox"/> 0-10V <input type="checkbox"/> 10-0V		(Common to all programs)
0-10V 1 function	<input type="checkbox"/> ventilation <input type="checkbox"/> heat lamp <input type="checkbox"/> heat mat <input type="checkbox"/> inlet		(Common to all programs)
0-10V 1 follows set point ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
0-10V 2 signal	<input type="checkbox"/> 0-10V <input type="checkbox"/> 10-0V		(Common to all programs)
0-10V 2 function	<input type="checkbox"/> ventilation <input type="checkbox"/> heat lamp <input type="checkbox"/> heat mat <input type="checkbox"/> inlet		(Common to all programs)
0-10V 2 follows set point ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Curtain 1 compensation ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Curtain 1 Whisker switch ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Curtain 2 compensation ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Curtain 2 Whisker switch ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use purge ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Variable fan outputs	<input type="checkbox"/> V1 <input type="checkbox"/> V1-V2 <input type="checkbox"/> Ramp.	<input type="checkbox"/> V1 <input type="checkbox"/> V1-V2 <input type="checkbox"/> Ramp.	<input type="checkbox"/> V1 <input type="checkbox"/> V1-V2 <input type="checkbox"/> Ramp.
Number of inlets	____ (0-2)	____ (0-2)	____ (0-2)
Inlet 1 mode	<input type="checkbox"/> Timer <input type="checkbox"/> Potentiometer		(Common to all programs)
Use misting ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Mist follows set point ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Use cool cell ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use stir fan ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use soaking ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use lights ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use backup relay ?	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No	<input type="checkbox"/> Yes <input type="checkbox"/> No
Use RP-16 ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
V1 Min speed	____ %		(Common to all programs)
V1 Motor curve	____ (1 - 10)		(Common to all programs)
V2 Min speed	____ %		(Common to all programs)
V2 Motor curve	____ (1 - 10)		(Common to all programs)
Use age ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Use Temp. curve ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Use Min. Vent. curve ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Number of programs	____ (1 - 3)		(Common to all programs)
Switch program	<input type="checkbox"/> Age <input type="checkbox"/> Outside T° <input type="checkbox"/> Manual		
Use password ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Clear alarms ?	<input type="checkbox"/> Yes <input type="checkbox"/> No		(Common to all programs)
Digit display	<input type="checkbox"/> T° <input type="checkbox"/> SP <input type="checkbox"/> T°/SP		(Common to all programs)

INDEX

A

- Age
 - see Animals
- Alarms
 - Alarm conditions 71, 72
 - Alarm log 71
 - Reset the alarm log 22
 - Alarm relay 73
 - Alarm settings 73
- Animals
 - Animal count
 - History 75
 - Posting changes to the animal count 76
 - Enabling animal age functions 22
 - Starting a new group 76

B

- Backup
 - Backup relay
 - Activation 21
 - Relay assignment 27
 - Making a backup of the controller 79
- Buttons 11–12

C

- Calibration
 - Inlet calibration
 - Loading an existing calibration 80
 - Operation & settings 56
 - Probe calibration 25
 - Water meter calibration 25
- Celsius units 18
- Clean mode
 - Alarms 72, 73
 - Clean mode set point 32
 - Operation & settings 30
- Clock
 - Display : AM/PM or 24hours 18
 - Setting the time and date 14
- Clock outputs
 - # of cycles 19
 - Activation 19
 - Current status 74
 - Operation & settings 66
 - Relay assignment 27
- Compensation
 - see Relative humidity compensation
- Connections 10

- Contrast (LCD screen) 12
- Controller
 - Features 7
 - Installation setup 19–22
 - Location of the controls 11
 - Mounting instructions 10
 - Software
 - Loading a new software 80
 - Version 31
 - Technical specifications 78
- Cool cells
 - Activation 21
 - Operation & Settings 58
 - Relay assignment 27
 - RH comp. on the cool cell output
 - Activation 23
 - Principle of operation 68
 - Settings 69
- Copy & Paste function 17
- Culled
 - History 75
 - Posting # of culled animals 76
- Current conditions 74
- Curtains
 - see Natural ventilation curtain
- Curves
 - Min. speed curve
 - Curve offset 38
 - Enable the curve function 22
 - Principle of operation 37
 - Settings 37
 - Motor curve 21
 - Temperature curve
 - Curve offset 34
 - Enable the curve function 22
 - Principle of operation 33
 - Settings 33

D

- Date 14
- Day / Night
 - Day/night times 29
 - Night set point
 - Principle of operation 32
 - Settings 32
- Display
 - Red LED display
 - Location 11
 - Unit selection 22

E

- Electrical specifications 78
- Evaporative pads
 - see Cool cells

F

- Fahrenheit units 18
- Fan stages
 - Activation 19
 - Current fan stage in use 74
 - Minimum ventilation
 - see Minimum ventilation
 - Principle of operation 39
 - Relay assignment 27
 - Settings 42
 - Timer relays
 - Principle of operation 39
 - Timer settings 42
 - Transition between stages 1 and 2
 - Principle of operation 40
 - Settings 42
 - Variable fans
 - Activation 20
 - Assignment 28
 - Current speed of the fans 74
 - Minimum fan speed 21
 - Principle of operation 39
- Fan stages (0-10V fans)
 - Activating 0-10 V outputs 19, 20
 - Operation & settings 43
 - Probe assignment 26
- Feeders
 - Activation 19
 - Relay assignment 27
 - Run time alarm
 - Principle of operation 72
 - Settings 73
 - Run time history 74
- Gallons 18
- H
 - Heat lamp (0-10 V)
 - Activating the 0-10 V output 19, 20
 - Operation & Settings 64
 - Probe assignment 26
 - Heat mats (0-10V)
 - Activating the 0-10 V output 19, 20
 - Operation & Settings 65
 - Probe assignment 26
 - Heaters
 - Activation 19
 - Current status 74
 - Operation & Settings 63
 - Probe assignment 26
 - Relay assignment 27
 - RH compensation on heaters
 - Activation 23
 - Principle of operation 68
 - Settings 69
 - Run time history 74
 - History menus 75
 - Humidity
 - see Relative humidity

I

Inlets (0-10V inlet output)

- Activation 19, 20
- Principle of operation 57
- Probe assignment 26
- Settings 57

Inlets (potentiometer-based)

- Activation 21
- Calibration
 - Loading an existing calibration 80
- Operation & settings 56
- Current position 74
- Principle of operation 54
- Relay assignment 27
- Settings 55

Inlets (timer-based)

- Activation 21
- Current position 74
- Principle of operation 50–51
- Relay assignment 27
- Resetting the position 53
- Settings 52

Inputs

- Activation 24
- List of available inputs 7

Installation setup 19–22

Installer password

- see Password

L

LCD screen

- Backlight button 12
- Contrast adjustment 12
- Location 12

LEDs

- LED display
 - Location 12
 - Unit selection 22
- LED meaning 13

Lights

- Activation 21
- Operation & settings 66
- Relay assignment 27

Liters 18

M

Main menu button 11

Marked animals

- History 75
- Posting # of marked animals 76

Measuring units 18

Memory card

- Erasing the card 80
- Transfer process 79–80

Menu selectors 11

Minimum ventilation

- Min speed curve
 - see Curves
- On Time ramping
 - see Ramping
- Principle of operation 35–38
- Relay assignment 28
- RH Compensation on min vent cycles
 - Activation 23
 - Principle of operation 68
 - Settings 69
- Settings 36–38

Misting output

- Activation 21
- Operation & settings 59–60
- Relay assignment 27
- RH compensation on the mist output
 - Activation 23
 - Principle of operation 68
 - Settings 69

Mortality

- Entering new mortalities 76
- History 75
- Posting # of mortalities 76

Motor curve 21

Mounting instructions 10

N

Natural ventilation curtain

- Outside T° compensation 46
- Outside T° set point 32
- Principle of operation 44
- Probe assignment 26
- Purge cycles 47
- Relay assignment 27
- Settings 45
- Shutoff fans
 - Principle of operation 46
 - Relay selection 27

Night

- see Day/night

O

Outputs

- Activation 19–22
- List of available outputs 7
- Relay assignment
 - Clearing the assignment 22
 - Making the assignment 27

Outside RH

- see Rel. Humidity (RH)

Outside T°

- see Temperature

P

Parameter adjustment 12

Password

Enable/disable the password 22

Entering/changing the password 15

Probe

- Activation 24
- Assignment 26
- Calibration 25
- Connection 10
- Extension 10
- Probe sets
 - Current probe set in use 74
 - Principle of operation 48
 - Probe assignment 26
 - Settings 49

Programs

- Automatic program switch
 - Activation 22
 - Settings 16, 22
- Copy/paste program settings 17
- Current program in use 74
- Enabling programs 22
- Principle of operation 16
- Program selection 16

Purge cycles

- Activation 20
- Operation & settings 47

R

Ramping (minimum ventilation)

- Activation 20
- Principle of operation 41

Relative humidity (RH)

- Inside RH sensor
 - Activation 24
 - Calibration 25
 - Current reading 74
 - History 75
- Outside RH sensor
 - Activation 24
 - Calibration 25
 - Current reading 74
 - History 75
- RH Compensation
 - Principle of operation 68
 - Settings 69
- RH set point 69

Relay panel 21

Relays

- Alarm relay 73
- Relay assignment
 - Clearing the assignment 22
 - Making the assignment 27
- Shutoff fan relays in natural ventilation
 - Principle of operation 46
 - Relay selection 27
- Timer relays
 - Principle of operation 39
 - Timer settings 42

S

Screens (LED & LCD) 12

Sensors

see Probes

Set points

RH set point

see Relative Humidity 69

Temperature set points 32

Setup (Installation) 19–22

Simulation (temperature) 31

Soaking

Activation 21

Operation & settings 70

Relay assignment 27

Static pressure (SP)

Current pressure level 74

Measuring units 18

Pressure alarms

Principle of operation 72

Settings 73

Probe history 75

SP Probe

Activation 25

Calibration 25

Stir fans

Activation 21

Operation & settings 61

Relay assignment 27

Symbols of the manual 6

T

Technical specifications 78

Temperature

Average room temperature

Current average T° 74

History 75

Probe assignment 26

Probe set 2 - probe assignment 26

Probe set 2 - temperature settings 49

Probe set in use 74

Inside temperature probes

Activation 24

Current probe readings 74

History 75

Probe assignment 26

Probe calibration 25

Outside temperature

Activation 24

Current probe reading 74

History 75

Outside T° set point 32

Probe calibration 25

Temperature alarms

Principle of operation 72

Settings 73

Temperature set points

Clean mode set point 32

Current set point 74

Night set point 32

Operation & settings 32

Outside T° set point 32

Temperature curve 33, 34

Temperature simulation 31

Temperature units 18

Test mode 31

Time

Setting the time and date 14

Time format 18

Tunnel ventilation

Activation 19

Current stage in use 74

Principle of operation 48

Probe set 2

Current probe set in use 74

Probe assignment 26

Temperature settings 49

Settings 49

U

Units 18

User password

see Password

V

Variable-speed fans

see Fan stages

Ventilation

Fans

see Fans stages

Min. ventilation

see Minimum ventilation

Version (software) 31

W

Warning messages 77

Water meter

Activation 24

Calibration 25

Consumption history 74

Measuring units 18

Water spill alarm 72, 73

Whisker switch 20, 46

Wiring 10

Worksheets 81–85

