



World Provider Innovative Heating Solutions



INFRACONIC™ Brooder Maintenance

L.B. White Forced Air Heater Maintenance Checklist

The last thing you need to worry about it are your swine heaters. L.B. White Infraconic Brooders work flawlessly for years when they're regularly maintained. Taking necessary precautions saves money in the short- and long-run when it's absolutely necessary to squeeze profit out of every dollar. The following heater maintenance checklist can help keep L.B. White Infraconic Brooders working at peak performance during the cold winter months.

At Each Turn

1. Review all labels. If new data plates and labels are needed, contact L.B. White for replacements.
Email: customerservice@lbwhite.com
Call: 800-345-7200 (toll-free)
2. Check and replace any wires that are frayed, cut or corroded at the terminal. This applies to spark ignition heaters only.
3. Replace any cut or nicked gas hoses and corroded fittings
4. Clean the brooder with compressed air, brush, rag or water.
(DO NOT use pressure washers—faucet pressure is acceptable.)
5. Clean the filter by shaking and washing with water. WARNING! Do not machine wash or use pressure washers (faucet pressure is acceptable).

