



M1208-23024-08C

PFACT230-24 INLET ACTUATOR


NOTE: Read ALL instructions over carefully before attempting to install the Inlet Actuator.

If you have any questions please call your local dealer or J&D Manufacturing at: 1-800-998-2398.
Or visit our website at: www.jdmfg.com


WARRANTY

J&D Mfg. warrants all products are free from defects in materials and workmanship under normal use for the period of one year from date of purchase and our warranty does not cover normal or regular wear and tear. J&D Mfg can repair or replace at our option, any product or part of the product that is found to be defective. Our warranty applies to materials only and does not include return freight, delivery, loss or damage to personal property, cost of removal or installation, any incidental or consequential damages or labor. This warranty does not apply to products which are misused, abused, altered, improperly installed or subject to negligence. All warranties must be approved through our warranty department. The original purchaser must present a copy of the invoice for the defective product. One year is our standard warranty unless specified on our literature or in the installation instructions/user manuals.

Actuator 230 Volts AC



Potentiometer 10 Kohms



M1208-23024-08C

PFACT230-24 INLET ACTUATOR


NOTE: Read ALL instructions over carefully before attempting to install the Inlet Actuator.

If you have any questions please call your local dealer or J&D Manufacturing at: 1-800-998-2398.
Or visit our website at: www.jdmfg.com


WARRANTY

J&D Mfg. warrants all products are free from defects in materials and workmanship under normal use for the period of one year from date of purchase and our warranty does not cover normal or regular wear and tear. J&D Mfg can repair or replace at our option, any product or part of the product that is found to be defective. Our warranty applies to materials only and does not include return freight, delivery, loss or damage to personal property, cost of removal or installation, any incidental or consequential damages or labor. This warranty does not apply to products which are misused, abused, altered, improperly installed or subject to negligence. All warranties must be approved through our warranty department. The original purchaser must present a copy of the invoice for the defective product. One year is our standard warranty unless specified on our literature or in the installation instructions/user manuals.

Actuator 230 Volts AC



Potentiometer 10 Kohms



PFACT115-24 INLET ACTUATOR


NOTE: Read ALL instructions over carefully before attempting to install the Inlet Actuator.

If you have any questions please call your local dealer or
J&D Manufacturing at: 1-800-998-2398.
 Or visit our website at: www.jdmfg.com


WARRANTY

J&D Mfg. warrants all products are free from defects in materials and workmanship under normal use for the period of one year from date of purchase and our warranty does not cover normal or regular wear and tear. J&D Mfg. can repair or replace at our option, any product or part of the product that is found to be defective. Our warranty applies to materials only and does not include return freight, delivery, loss or damage to personal property, cost of removal or installation, any incidental or consequential damages or labor. This warranty does not apply to products which are misused, abused, altered, improperly installed or subject to negligence. All warranties must be approved through our warranty department. The original purchaser must present a copy of the invoice for the defective product. One year is our standard warranty unless specified on our literature or in the installation instructions/user manuals.

Actuator 120 Volts AC



Potentiometer 10 Kohms



PFACT115-24 INLET ACTUATOR


NOTE: Read ALL instructions over carefully before attempting to install the Inlet Actuator.

If you have any questions please call your local dealer or
J&D Manufacturing at: 1-800-998-2398.
 Or visit our website at: www.jdmfg.com

WARRANTY

J&D Mfg. warrants all products are free from defects in materials and workmanship under normal use for the period of one year from date of purchase and our warranty does not cover normal or regular wear and tear. J&D Mfg. can repair or replace at our option, any product or part of the product that is found to be defective. Our warranty applies to materials only and does not include return freight, delivery, loss or damage to personal property, cost of removal or installation, any incidental or consequential damages or labor. This warranty does not apply to products which are misused, abused, altered, improperly installed or subject to negligence. All warranties must be approved through our warranty department. The original purchaser must present a copy of the invoice for the defective product. One year is our standard warranty unless specified on our literature or in the installation instructions/user manuals.

Actuator 120 Volts AC



Potentiometer 10 Kohms

