

PMSEQ1

ITEM	VAL P/N	DESCRIPTION
1	PMSEQPANENCL	Enclosure, base and cover
2	PMMITCONTROL24V	Controller, with program
3	PM24VACPS63VA	Control transformer, 230VAC/24VAC
4	PMLIGHT24V	Front panel lamp
5	PMSWITMANH-O-A	Front panel switch
6	PMDILOAM	Contactoer
7	PMSCREWTERM	Terminal block
8	PM250VFUSE1A	1A fuse
9	PM250VFUSE2A	2A fuse
10	PMFUSEHOLDER	Fuse terminal block
11	PMSCREWTERMSEP	Terminal block separator
12	PMSCREWTERMEND	End stop, DIN mount
13	PMMY2AUXRELAY	Relay
14	PMMAINSW	Main switch
15	PMSIGNMOA	Front panel label
16	PMSIGNCOOLING	Front panel label
17	PMGROUNDTERM	Gound terminal block
18	PM16-20AOVLOAD	Manual motor starter, overload
19	PMAUXCONT1NO1NC	Auxiliary contact
20	PMCODELABEL1	Term block label
21	PMCODELABEL2	Term block label
22	PMRLYSOCKET	Socket, relay
33	PMJMPRSCRWTERM	Jumper, terminal block
34	PMTOGGLEBOOT	Sealing boot, F P switch
37	PMCODELABELL1	Term block power label
38	PMCODELABELL2	Term block power label
39	PMCODELABELN	Term block power label
40	PMCOVERLABEL	Front panel logo label
41	PMTOGGLENUT	Spacer nut, F P switch
42	PMTOGGLEWASH	Washer, seal, F P switch