

RVS-28HA DIP SWITCHES
(LOCATED INSIDE FRONT COVER)

DESCRIPTION	SWITCH POSITION	OPERATING MODE
LOCKING THE PARAMETERS	ON / OFF	UNLOCKED PARAMETERS
RESERVED	RESERVED	RESERVED
PROBE 2	ON / OFF	ENABLED / DISABLED
PROBE 3	ON / OFF	ENABLED / DISABLED
PROBE 4	ON / OFF	ENABLED / DISABLED
HEATING STAGES	ON / OFF	HEATING / NO HEATING
NUMBER OF STAGES	ON / OFF	2 HEATING STAGES
ZONED / CASCADED HEATING	ON / OFF	ZONED HEATERS / CASCADED HEATERS
MIST	ON / OFF	MIST ON / MIST OFF
OFFSET ON TEST STAGES	ON / OFF	OFFSET ON TEST STAGES / OFFSET OFF
DE-ICING	ON / OFF	ENABLED / DISABLED
RESERVED	RESERVED	RESERVED

UPDATED 8/29/05

SEPARATE PROBES EVENLY WITHIN THE AREA THAT IS TO BE CONTROLLED IF MORE THAN ONE PROBE IS USED.

