

ASSEMBLY INSTRUCTIONS FOR KIT AC52-0161 USED IN CC DARKOUT CONTROL PACKAGE E320-A0034

*Attach Whisker Switch Guide Bracket to end of U-bolt
as shown using the two 3/8 - 16 Hex Nuts provided.*

