

Technical Bulletin

CTN-1

Tunnel ventilation controller PUSH TO SET STAGE 1-2 SIDEWALLS ENDWALL\$ ROOM TEMPERATURE STAGE 4 STAGE 5 __SET PGINT / T1 CURVE OUTSIDE-MIST / HEATER T° CURVE TIMER STAGE PROBE DEFECT DIFFERENTIAL 4-5 -BAND WIDTH MODEL CTN-1 DEAD BAND

Features

Can control:

One heater

Two Cooling contact for minimum ventilation (1 variable)

Sidewall curtain output & Endwall curtain output

Two Cooling contact for tunnel fans

One evaporating cooling pad or mist system

Curve to automatically adjust Set point with animal's age

Up to 3 inside temperature probes with individual readout

Outside temperature probe to allow tunnel mode

Computer Compatible

Overload and overvoltage protection

Can be powered with 115/230 Vac (60Hz) or 12Vdc