NORSOL

CTN-4

Tunnel ventilation controller

73.1

- STAGE 1-2
- SIDEWALLS
- ENDWALLS
- TUNNEL 1
- TUNNEL 2
- MIST/HEATER
- T° CURVE
- PROBE DEFECT

MODEL CTN-4

PUSH TO SET

TEMPERATURE CURVE

SET

ROOM TEMPERATURE

OUTSIDE SETTINGS — SET POINT / T° CURVE
HEATER OFFSET — TIMER   STAGE 1
MIST   TIMER — DIFF.
DIFFERENTIAL — DIFFERENTIAL 2
DIFFERENTIAL 4-5 — TIMER   CURTAINS
DEAD BAND

Features

Can control :
  One heater
  Two Cooling contact for minimum ventilation
  Sidewall curtain output & Endwall curtain output
  Two Cooling contact for tunnel fans
  One evaporating cooling pad or mist system
Curve to automatically adjust Set point with animal's age
Up to 3 inside temperature probes with individual readout
Outside temperature probe to allow tunnel mode
Computer Compatible
Can be powered with 115/230 Vac (50 & 60Hz) or 12Vdc